

LA-UR-02-7426

Approved for public release;
distribution is unlimited.

Title: Deuterium Adsorption on Water Preadsorbed
Uranium-Niobium Alloys

Author(s): Thomas A. Jachimowski, Mark T. Paffett, Daniel (NMI) Kelly,
Robert J. Hanrahan Jr.

Submitted to: Annual American Physical Society March Meeting, March
3-7, 2003; Austin Convention Center; Austin, TX



Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the University of California for the U.S. Department of Energy under contract W-7405-ENG-36. By acceptance of this article, the publisher recognizes that the U.S. Government retains a nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

Form 836 (8/00)



"Deuterium Adsorption on Water Preadsorbed Uranium-Niobium Alloys"

Tom Jachimowski, Mark Paffett, Robert Hanrahan, and Dan Kelly
Los Alamos National Laboratory

We have investigated the adsorption/reaction of deuterium on water preadsorbed oxidized uranium-niobium alloys at pressures near 1 Torr. Deuterium exposures were conducted at pressures from 1 to 4 Torr at surface temperatures between 300 and 600 K using a fixed dosing time of 30 seconds. Water is preadsorbed at room temperature at a pressure of ~ 1 Torr for 30 seconds. Subsequent to gaseous exposure the surface temperature of the alloy was increased in a controlled manner and deuterium desorption was monitored using mass spectroscopy. Deuterium is observed to adsorb both at the surface and in the bulk of the uranium-niobium alloys. Water preadsorption prevents deuterium adsorption on all surfaces. The water forms a surface passivation layer at low temperatures that prevents deuterium uptake into the bulk and surface of the sample. As the adsorption temperature of the deuterium increases the amount of deuterium that adsorbs also increases.