LA-UR-12-23189

Approved for public release; distribution is unlimited.

Title: A Tale of 2 Missions (And Hopefully 2 Different Landings)

Author(s): Wiens, Roger C.

Intended for: LANL IGPP Annual Review Dinner, 2012-07-17 (Santa Fe, New Mexico,

United States)




Disclaimer:

Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer,is operated by the Los Alamos National Security, LLC for the National NuclearSecurity Administration of the U.S. Department of Energy under contract DE-AC52-06NA25396. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Departmentof Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.





This talk, to be given at the LANL IGPP Annual Review dinner in Santa Fe, NM on July 17, 2012, highlights two important NASA missions LANL played a key role in: The Genesis mission was the first to return to Earth from beyond the Moon, bearing solar particles to help understand the composition of the Sun; and Curiosity, a 1-ton Mars rover launched to the red planet in 2011 with a suite of instruments from LANL called ChemCam.

There are 2 embedded videos in this presentation: The first is a short clip on the crash landing of the Genesis capsule, edited by John Bass at LANL, and the second is a < 10 second clip showing a close-up image of laser-induced breakdown plasmas, which has been shown in other LAUR'd presentations.



Apollo Solar Wind Composition Experiments

- Collected solar wind ions implanted in foil
- Determined solar He & Ne isotopes
- Was the impetus for Genesis—a longer, purer solar-wind collection



GENESIS Science Objectives


 To Collect Samples of the Solar Wind and Return them to Earth

 To accurately determine the Composition of the Sun



Oxygen Isotope Map of Solar System Los Alamos









Oxygen Isotope Map of Solar System Los Alamos





Roger C. Wiens

8% Effect è BIG!





Testing Space Hardware at the Rifle Range




(Faster, better, cheaper...)








GENESIS MISSION TRAJECTORY: 2001 — 2004





LANL Solar Wind Concentrator









Solar System Oxygen










Laboratory Self Shielding & N₂ Story




- IGPP funding supported laboratory verification of the self-shielding effect for oxygen (rt.)
- The Genesis Concentrator also permitted solar nitrogen isotopic analyses
 - The result: ¹⁵N is even more isotopically depleted in the Sun than the rare O isotopes
 - IGPP-supported work at UC Davis showed that UV-dissociated N₂ is more reactive than O, resulting in a 5x stronger self-shielding capture effect for nitrogen




ChemCam






Laser-Induced Breakdown Spectroscopy (LIBS)




Laser-Induced Breakdown Spectroscopy (LIBS)




LIBS Movie

Laser-Induced Breakdown Spectroscopy (LIBS)





LIBS Spectrum (1 of 3)



Why LIBS on Mars?


Eagle Crater, First Sedimentary Outcrop Observed on Mars

- n Mars is a Difficult Place For Remote Sensing
 - Surfaces Typically Covered by Dust and/or Weathering Coatings
 - n Active Remote Sensing Much Better Than Passive

Under These Circumstances

Not Initially Identified by Remote Sensing on the Opportunity Rover

n Most Samples Had to Be Brushed Off Before Identification







K9 Rover Test

- LIBS integrated on a NASA rover testbed
- Our opportunity to prove the usefulness of LIBS!
- Scheduled for May 11, 2000





Spectrometers (inside rover body)



The fire evacuation prevented us from participating in the rover tests!!

ChemCam Instrument Schematic






ChemCam MicroImager Performance

\$1 @ 10 ft distance





ChemCam Micro-Imager Performance



Chemostratigraphy Example: Banded Iron Formation

Rover test





ChemCam RMI Subframe Stretched




Distance between analysis points ~2 mm














Curiosity Rover




Curiosity Instruments






Previous and Future Mars Landing Sites





The Strata of Gale Mountain




Gale Crater contains a 5-km high mound of stratified rock. Strata in the lower section of the mound vary in mineralogy and texture, suggesting that they may have recorded environmental changes over time. Curiosity can investigate this record for clues about habitability, and the ability of Mars to preserve evidence about habitability or life.




Gale Crater (4.5 ° S, 137 ° E, -4.5 km)

- 3-mile thick sequence of rock layers
- Clay-rich near the bottom, sulfates at higher elevations.






Mars Landing





Curiosity will be an exciting mission, going beyond finding water, to surveying the habitability and climate history of Mars



Thank you for hosting this presentation

...and thanks to the many people at Los Alamos and elsewhere who contributed to these missions!



Additional Slides




ChemCam Science Measurements

- Weathering Coatings on Rocks
- Depth Profiles in Soils
- General Elemental Compositions of Rocks/Soils
- Particular Emphasis on Elements Not Analyzable by Other Means:
 - Hydrogen (i.e., clay minerals)
 - Carbonates
 - Li, Be, B, N, Rb, Sr, Ba
- Tactical Support/Reconnaissance for Rover Team
- Passive spectroscopy
- Atmospheric Ozone Studies (Passive Observation in the UV)
- Support for LIDAR studies of atmospheric dust and water vapor



ChemCam Operations

- First 90 days: Operate at Jet Propulsion Laboratory, on Mars time (24 hr, 38 minute days)
- After that, operate from home. Operate ½ from France, ½ from US on 37 day cycles (36 Mars sols = 37 days)





Rover Arm






Aeroshell "Fit Check"









Buildup for Launch: Rover and EDL Stage







Rover in Capsule





Typical analysis sequence









Surface Operations Overview

Mission Segment:



Sol Types / Decision Points



•

Top-Level ChemCam Requirements

- n Measure major elements to ±10% accuracy
- n Analysis distances to 7 m
- n Capable of up to 10 measurements/day
- n Provide depth profiles to 1 mm deep
- n Individual shot analyses
- n Provide context images for analyses
- Provide rapid analyses (goal 5 min./analysis)






Derived ChemCam Requirements

- n Spectral range 242-800 nm
 - n To cover C (strongest line 248 nm) and O (strongest line 777 nm)
- n Spectral resolution
 - $_{\rm n}$ < 0.20 nm FWHM for λ < 470 nm
 - Separates 248 nm C line from Fe interference and 407.7 nm Sr line from Fe interference
 - < 0.65 nm FWHM for $\lambda > 470$ nm
 - Fewer and more widely spaced interferences in this spectral range
- n Laser power density > 10 MW/mm²
 - Needed to create LIBS sparks
- n Imager resolution $\leq 100 \, \mu \text{rad}$
 - n To image LIBS analysis pits
- n Laser rated to 5 million shots, passively cooled
- n Requirements on transmission and signal-to-noise







ChemCam Mast Unit : Optical Box



Laser


- Passively cooled
- n Up to 35 mJ output
- $\sim 500 g$






Demultiplexer and Spectrometers

- Optical demultiplexer receives light from Mast Unit, optimizes light going to each spectrometer
 - Output feeds fiber bundles linearly aligned to spectrometer slits
- Spectrometers are identical structurally, but with different gratings and surface coatings
- n Spectral ranges
 - n 240-335 nm @ < 0.2 nm FWHM
 - n 385-465 nm @ < 0.2 nm FWHM
 - n 500-850 nm @ < 0.45 nm FWHM







3. Projection and clustering methods

Igneous rocks at 5 m thermo-vacuum tests


Non-linear Bi-dimensional projection minimizing:

$$E = \frac{1}{\sum_{i < j} d_{ij}^*} \sum_{i < j} \frac{(d_{ij}^* - d_{ij})^2}{d_{ij}^*}.$$

d_{ij}=initial space distance between i and j d^{*}_{ii}=map distance between i and j

•In this case 2 times better than PCA for visual representation of the dataset.

ICA planned to be used by ChemCam







Quantification of elemental composition


Results PLSR at 5 m thermo-vacuum tests for 11 igneous standards

Using PLSR, the median of the relative accuracy predictions for unknown samples is shown (one sample left out statistics).

The accuracy of the predictions are typically of the order of 10% or lower.

The quantities of Mn, K, Ti to be predicted are the lowest (<10⁻³) which can explain the relative accuracy increase.









Quantification of elemental composition

Results PLSR at 5 m thermo-vacuum tests


Here, the PLS model includes some spectra of the sample we are trying to predict.

The accuracy of the predictions are 10% or lower for all elements.

The predicted spectrum is never used to generate the model.

Calibration based on most similar analogues will give best results.

5 m PLS relative accuracy prediction









Mars Science Laboratory Goals

- Assess Mars' <u>biological potential</u> by
 - Searching for organic carbon compounds,
 - Looking for the chemical building blocks of life,
 - Identify biologically relevant clues.
- Characterize the geology of the landing region
- Investigate Mars' past <u>habitability</u> (including the role of water)
- Characterize the <u>human hazards</u> on Mars

