LA-UR- 11-01369

Approved for public release; distribution is unlimited.

Title:

Qualitative comparison of Benchtop (415KeV) and Synchrotron (215KeV) X-rays and 800 MeV protons for tomography of 5mm diameter Urania cylinders

Author(s):

M. Bourke, J. F. Hunter, D. Brown D. Byler UO2 C.F. Chen J.F. Hunter, D. Brown

G. Hogan , K. Kwiatkowski, F. G. Mariam, F. Merrill, C. L.

Morris, and A Saunders

Jeff Terry, Jeremy Kropf, Dan Olive

Intended for:

Oral Presentation at TMS Annual meeting; San Diego Feb 28th to March 3rd 2011



Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the Los Alamos National Security, LLC for the National Nuclear Security Administration of the U.S. Department of Energy under contract DE-AC52-06NA25396. By acceptance of this article, the publisher recognizes that the U.S. Government retains a nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

## Qualitative comparison of Benchtop (415KeV) and Synchrotron (215KeV) X-rays and 800 MeV protons for tomography of 5mm diameter Urania cylinders

M. A. M. Bourke, D. W. Brown, D. D. Byler, C. Chen, J. F. Hunter, J. Kropf, F.G. Mariam, C. Morris, A. Saunders

Two surrogate nuclear fuel types were examined with three radiographic probes. The samples were rods (a few cm long) of urania and thoria-ceria that were 5mm and 10mm in diameter respectively. Spatial and density heterogeneities were introduced with inclusions during sintering and by altering the sintering conditions during powder consolidation. Three radiographic tools were used; benchtop (425 KeV ) X-rays, synchrotron (225KeV) X-rays and 800 MeV protons. Tomographic reconstructions were produced. The spatial and density resolutions achieved with the different techniques are compared as well as the potential for their improvement. The potential application of the different techniques to highly radioactive samples will also be considered.

## Qualitative comparison of Benchtop (415KeV) and Synchrotron (215KeV) X-rays and 800 MeV protons for tomography of 5mm diameter Urania cylinders

M. Bourke, J. F. Hunter, D. Brown

Sample preparation D. Byler UO2 C.F. Chen (Thoria - Ceria)


LANL / Benchtop J.F. Hunter , D. Brown

LANL / PRAd measurements G. Hogan , K. Kwiatkowski, F. G. Mariam, F. Merrill, C. L. Morris, and A Saunders

APS for SXR measurements Jeff Terry, Jeremy Kropf, Dan Olive

[Outline]
Context
Why
Radiography other
Tomographic reconstruction
Sample Fabrication
Three techniques
Comparison of salient features
Wedges
Density
Resoultion estimates
Optimization opportunities

Conclusions







Operated by Los Alamos National Security, LLC for NNSA


UNCLASSIFIED





















	BENCHTOP X-Ray	Protons	Synchrotron X-Ray
Energy	415 KeV	800 MeV	215 KeV
Sample to Detector	~ 2 m	~ 8 m	
Source to Sample	~ 2 m		~ 27 m
Detector Pixel	~ 130 µm	~ "25 μm" with X3 mag. (~ 70 μm)	~ 6 µm
Source	Phillips 450 adjustable tube	LANSCE	ID-10 Advanced Photon Source
Filter	2mm Sn, 0.5mm Cu		0.8mm Al, 0.83mm Cu, 2.0mm Sn, 0.4mm Ta, 4.8mm Pb
Frames per second	20 Avg, 0.5fps, 150 views		
Collimation	Tapered tungsten Collimator against tube coffin + rectangular leaf collimator 11 inches from the part.		
Spot Size	~ 1 mm		
Misc.			Cadmium tungstate detector 5 10 e4 photons/s / 4pi




















## Conclusions



- Smallest features seen here approx 5 um
- Density determination by PRAd was within 1%
- SXR demonstrated best resolution
- All three techniques would benefit from improved detectors
- Field of view was largest for PRAd
- All measurements completed in less than a few minutes
- View through cladding not a problem

UNGLASSIFIED



