

LA-UR-14-28067

Approved for public release; distribution is unlimited.

Title: Neutron Imaging to optimize PEM Fuel Cell Performance

Author(s): Mukundan, Rangachary

Borup, Rodney L. Spernjak, Dusan

Wu, Gang

Steibach, Andrew Zelenay, Piotr Hussey, Daniel Jacobson, David

Intended for: Slides for Distribution

Issued: 2014-10-16



NEUTRON IMAGING TO OPTIMIZE PEM FUEL CELLS PERFORMANCE

Rodney Borup^{a,} Rangachary Mukundan^a, Dusan Spernjak^a, Gang Wu^a, Andrew Steinbach^b, and Piotr Zelenay^a, Daniel Hussey^c, David Jacobson^c

> ^aLos Alamos National Laboratory ^b3M Company

^cNational Institute of Standards and Technology



Outline

- Introduction
 - Visualizing water using neutron imaging
 - Role of water/Gas Diffusion layers (GDL) in PEM Fuel cells
- Neutron visualization applied to
 - Standard Pt/C based MEAs
 - 3M NSTF MEAs
 - Non-precious metal catalyst MEAs
- Summary / Future Work

Acknowledgements

U.S. Department of Energy for funding through Office of Fuel Cell Technologies (EERE). Nancy Garland and Dimitrios Papageorgopoulos




Visualizing Water Using Neutron Imaging



Fuel Cell Design for High-Resolution Neutron Imaging

Previous work, XDL 25 μm detector





Advantages:

- Observe and distinguish between MEA and anode and cathode GDLs and flow fields in x-section
- The high resolution (~13 μm) MCP detector provides the capability of resolving the water content of these thin fuel cell components
- 1 mm X 1 cm slit. L/D= 6000; L/D=600

Fuel Cell Design Constraints:

- Maximum field of view is 3.5 cm X 3.5 cm
- Outermost fuel cell edge in neutron beam path should be no more than 3 cm from detector for good imaging
- The neutron beam should not pass through more than 1 cm of cumulative liquid water and there should be minimal hydrogen containing compounds in the neutron beam path

Our Cell:

- Active area: 2.25 cm², 1.12 cm X 2.0 cm
- Hardware = gold plated aluminum, gaskets = fiberglass reinforced PTFE
- ~ 1 cm active-area beam path length
- Shallow single serpentine flow field channel (0.6 mm wide X 0.25 mm deep). Realistic pressure drop: ~ 1/3rd that of the 50 cm² cell




Role of water/Gas Diffusion Layers (GDL) in PEM Fuel cells



Water in PEM Fuel Cells

 H₂O fluxes: in An & Ca gas feed stream, electro-osmotic drag (An→Ca), Ca formation, back-diffusion (Ca→An), and in An & Ca exhaust streams


 GDLs are responsible for ensuring optimal H₂O transport (liquid and vapor) in and out of the MEA, without inhibiting reactant and product transport



Critical for very thin (NSTF) and very thick (non-precious metal) catalyst layers



Water management in conventional Pt- based MEAs Gas Diffusion Layer (GDL) modifications




Keep liquid water out of cathode catalyst layer
Avoid liquid water accumulation in GDL and flow
fields

SGL/LANL: Published papers on additives
to the MPL to improve water management


to the MPL to improve water management 3M: Published papers on water removal through anode (either vacuum or special anode GDLs)

Keep membrane and catalyst layer ionomer wet

These strategies are directly applicable to thick non-PGM electrodes




10% Aluminosilicate fibers mixed in with standard MPL mixture of carbon black + PTFE (23w%). MPL treated at 350 °C





Performance of various GDLs (Conventional Pt MEA)



Performance improvement at high current for 25BL and 25BN in H₂/ Air. Similar performance for 3 GDLs at low current densities and in HelOx

- 25BC = standard MPL (carbon+PTFE+binder) BASELINE
- 25BL = standard MPL with hydrophilic treatment: Mass-transport improvement; Durability issues
- 25BN = standard MPL with C-nanotubes: More mass-transport improvement; Durability good

50 cm² cell, quad serpentine, MEA = Gore PRIMEA A510.2/M710.18/C510.4; 80° C, 100% RH, 1.2/2 stoich, 28.4 psi backpressure




Standard Pt/C MEAs



Water profile across the cell thickness at fixed current

- <u>25BC</u> = standard MPL (carbon+PTFE+binder): Higher CL water content than BL or BN
- <u>25BL</u> = standard MPL with hydrophilic treatment: Liquid water in the MPL
- <u>25BN</u> = standard MPL with C-nanotubes: Least amount of water everywhere 2.5 cm² cell, single-serpentine, MEA = Gore PRIMEA A510.2/M710.18/C510.4 80° C, 100% RH, 100/200 sccm, zero backpressure







Low current performance un-affected by water


0.4 A/cm²

Maximum water observed in BL GDL (hydrophillic channels in MPL)

Little difference in performance observed











Performance improved with decrease MEA water content


0.8 A/cm²

Maximum water observed in BL GDL and minimum water observed in BN GDL

Catalyst/MEA water is lowest in BN GDL and performance is best











Performance improved with decrease MEA water content


1.2 A/cm²

Water content initially increase with increasing current and then stabilizes due to heat generated

Anode water is low










NSTF MEAs




3M NSTF: Water Management


A. J. Steinbach, M. K. Debe, J. L. Wong, M. J. Kurkowski, A. T. Haug, D. M. Peppin, S. K. Deppe, S. M. Hendricks, and E. M. Fischer *ECS Trans.*, **V33(1)**, p47 (2010),





Imaging results (NSTF)







New anode GDL: 4X higher current at 0.3 V, yet less water in the MEA and lower impedance

MRC U105










Non-precious metal catalyst based MEAs




Water content (non-PGM catalyst)






Managing water by varying GDLs (non-PGM MEA)



Water peak at cathode catalyst layer

Increases with increasing currents with conventional GDLs


Lower water contents in cathode with 3M anode and BN cathode GDLs (Removal of water through anode)





Fuel Cell Performance of PANI-Fe-KJ Cathode Using Different GDL

Anode: 2.0 mg cm⁻² Pt; Cathode: 4.1 mg cm⁻² Cell: 80°C; 100% RH, Membrane: Two Nafion® 212



Mass transport significantly affects performance at i ≥ 0.2 A/cm²

- As we use commercial anode GDE, GDL used in the anode for both MEAs are the same.
- Significant performance enhancement in mass transfer range was observed with advanced cathode GDL.



Summary/Future work

High resolution neutron imaging used to study/ optimize fuel cell performance

- Control water removal to minimize catalyst layer water content
- GDL water content indirectly controls performance
- Anode water removal is viable strategy for emerging fuel cell cathodes

Future Work

 Improve resolution and cell design to directly quantify cathode water saturation levels

