

## LA-UR-17-22111

Approved for public release; distribution is unlimited.

Title: Effects of Shielding on Gamma Rays

Author(s): Karpus, Peter Joseph

Intended for: DHS/FEMA Spectroscopy Course

Issued: 2017-03-13

---

**Disclaimer:**

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the Los Alamos National Security, LLC for the National Nuclear Security Administration of the U.S. Department of Energy under contract DE-AC52-06NA25396. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.



# Effects of Shielding on Gamma Rays

Pete Karpus


Mar 2017

# Introduction

- The interaction of gamma rays with matter results in an effect we call attenuation (i.e. 'shielding')
- Attenuation can dramatically alter the appearance of a spectrum
- Attenuating materials may actually create features in a spectrum via x-ray fluorescence

UNCLASSIFIED

# Radiation Types and Shielding




UNCLASSIFIED

# Attenuation / Transmission

- $T = \exp(-\mu / \rho * \rho * x)$
- T is transmission of uncollided photons (i.e. the gamma rays still have their original full energy)
- $\mu / \rho$  is mass attenuation coefficient and varies with Z and energy
- $\rho$  is density of shielding
- x is thickness in cm
- Applies to 'loss' of full-energy gamma-rays only

UNCLASSIFIED

# Attenuation / Transmission



**Attenuation:**  $I = I_0 e^{-\mu x}$

$\mu$  = linear attenuation coefficient ( $\text{cm}^{-1}$ )  
 $x$  = thickness (cm)

**Transmission:**  $T = I/I_0 = e^{-\mu x}$

UNCLASSIFIED

# Mass vs Linear Attenuation Coefficients

- Linear attenuation coefficients depend on density
  - Ice, water, water vapor all have different linear attenuation coefficients
  - Units are  $\text{cm}^{-1}$
  - Some texts use  $\mu$  some texts use  $\mu_{\ell}$
- Mass attenuation coefficients are independent of density

$$\mu_{mass} = \frac{\mu_{linear}}{\rho}$$

- Ice, water, water vapor all have same linear attenuation coefficients
- Units are  $\text{cm}^2/\text{g}$


UNCLASSIFIED



# Attenuation and Atomic Number

At incident photon energies below  $\sim 1$  MeV, the  $Z$  of the shielding material matters because this is where the photoelectric effect dominates.


At around  $\sim 2$  MeV the Compton Effect dominates and the probability for interaction becomes independent of  $Z$ .




UNCLASSIFIED

# Mass Attenuation Curve Examples

Fe Absorption vs. Energy



Pb Absorption vs. Energy




UNCLASSIFIED

# Effect of Shielding on Peaks

- Reducing peak amplitude (area)
  - Differential Attenuation:
    - low-energy peaks affected more than high-energy peaks
    - Peaks with similar energies are similarly affected
  - more pronounced with higher Z shielding materials
- Creates continuum 'step'
  - caused by multiple and small-angle scattering
  - proportional to local peak amplitudes (areas)
- Fluorescent X-rays are sometimes visible
  - E.g. Pb x-rays are produced by Pb shielding


UNCLASSIFIED

# 0.75" Fe Shielding Eu-152



UNCLASSIFIED


# 6.5 cm Pb Shielding Ir-192




UNCLASSIFIED

# Transmission is Multiplicative

Shielding of the same type and thickness ,  $x$




Let's say 1,000,000 gammas at same energy as above are incident upon an attenuator of the same type above but of twice the thickness.



UNCLASSIFIED

# Half-Value Layers

A half-value layer (HVL) is the amount of material required to reduce the radiation intensity at a specific energy by  $\frac{1}{2}$ .



| Energy [keV] | H2O [cm] | Fe [cm] | Pb [cm] | U [cm] |
|--------------|----------|---------|---------|--------|
| 60           | 3.4      | 0.070   | 0.012   | 0.005  |
| 186          | 5.0      | 0.6     | 0.05    | 0.025  |
| 414          | 6.6      | 1.0     | 0.3     | 0.14   |
| 1001         | 9.8      | 1.5     | 0.9     | 0.5    |
| 2614         | 16.2     | 2.3     | 1.4     | 0.8    |


UNCLASSIFIED



# Infinite Thickness

What if we use 10 half-value layers?

Transmission,  $T$ , through  
one HVL is  $1/2$


$$T^{10} = \left(\frac{1}{2}\right)^{10} \cong \frac{1}{1000}$$

Only one photon out of a thousand gets through 10 HVLs.  
For all practical purposes, we can consider these photons  
**COMPLETELY SHIELDED.**

UNCLASSIFIED



# How much shielding to kill 186 keV?

As an example let's look at what it takes to totally shield the main, direct gamma-ray signature of  $^{235}\text{U}$ , that is the peak at 186 keV.



- To kill the main  $^{235}\text{U}$  signal you need:
  - Water: ~ 50 cm
  - Fe: ~ 6 cm
  - Pb: ~ 0.5 cm
  - U: ~ 0.25 cm

**If you surround HEU with more than 2.5 mm of DU, the only direct  $^{235}\text{U}$  gamma rays that you will see will come from the DU itself.**

UNCLASSIFIED


# Bare vs. Shielded HEU

Measurements of 9x9" HEU (93%  $^{235}\text{U}$ ) foils (~350 g total) in a film can were conducted in both bare and shielded configurations.




UNCLASSIFIED

# HEU Shielded by 0.5" of Steel




UNCLASSIFIED

# HEU Shielded by 0.5" of Steel



UNCLASSIFIED


# HEU Shielded by 0.5" of Steel



UNCLASSIFIED




# HEU Shielded by 0.25" of Pb



UNCLASSIFIED

# HEU Shielded by 0.25" of Pb



UNCLASSIFIED


# Shielding Effects on Continuum

- What produces counts in the continuum?
  - Compton scattering in the detector medium
  - Compton scattering in the source itself
  - Compton scattering in the rest of the environment
    - I.e. ground, air, walls, detector electronics, people, and **shielding**, etc.
- How to get zero continuum?
  - Infinite detector medium + point source in a vacuum
- Scattering produces continuum counts to the low-energy side of the full-energy peaks

UNCLASSIFIED



# Scattering without Shielding



UNCLASSIFIED

(air)

## Shielding


source



NSA  
National Nuclear Security Administration


# X-Ray Fluorescence (XRF)

Gamma rays from the source ionize the attenuating material via the photoelectric effect (shown) or the Compton effect, resulting in the emission of characteristic x rays.



UNCLASSIFIED


# 0.5 cm of Pb producing X-Rays with Xe-133



UNCLASSIFIED


# X ray Peak Patterns

Since all elements build on the same inner-shell electron structure, peaks from characteristic x rays exhibit the same pattern, only shifted by energy, within the limits of detector resolution.



UNCLASSIFIED

# Pb XRF in a HPGe Spectrum



**What indicates that these x rays might be from a Pb collimator and not Pb shielding the source?**

UNCLASSIFIED

# Making Predictions

## ■ Low-Z shield


- peak attenuation less dependent on energy
  - less of a difference between how much low- and high-energy peaks are attenuated
- low-energy photons will more likely undergo Compton scattering raising the low-energy continuum

## ■ High-Z shield

- peak attenuation more dependent on energy
- low-energy photons will more likely undergo photoelectric absorption and not contribute to the continuum
- for high-activity sources, strong, low-energy peaks can be completely masked, leaving only weaker, high-energy peaks, Example: Ir-192

UNCLASSIFIED

# Shielding Order Effects



UNCLASSIFIED



# Rules of Thumb

- For a given source, all energies are attenuated, but low-energy photons will be attenuated more than high-energy
- Higher  $Z$  shielding increases attenuation of lower-energy gamma-rays relative to higher-energy gamma-rays
- Shielding and scatter cause 'steps' under peaks and add counts to the Compton continuum to the left of the peaks
- For most shielding materials, one can predict attenuation for gamma-rays above 400 keV based only on the effective shielding density and thickness.

UNCLASSIFIED