

LA-UR-17-30100

Approved for public release; distribution is unlimited.

Title:	Non-Invasive Acoustic-Based Monitoring of Heavy Water and Uranium Process Solutions
Author(s):	Pantea, Cristian Sinha, Dipen N. Lakis, Rollin Evan Beedle, Christopher Craig Davis, Eric Sean
Intended for:	Spent Fuel Non-Destructive Assay (NDA) Annual Project Meeting/Arden Dougan (NA-241, SG Tech) & Sean Stave (PNNL, M&O for SG Tech) Visit Report
Issued:	2017-11-02

Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the Los Alamos National Security, LLC for the National Nuclear Security Administration of the U.S. Department of Energy under contract DE-AC52-06NA25396. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.



Non-Invasive Acoustic-Based Monitoring of Heavy Water and Uranium Process Solutions

**Cristian Pantea, Dipen Sinha, Rollin Lakis, Chris Beedle,
Eric Davis**

Oct 26, 2017

UNCLASSIFIED

Agenda

- Introduction
- Heavy Water Challenge
- Swept-Frequency Acoustic Interferometry
- Results for Heavy Water Experiments
- Uranium Process Solution Challenge
- Results for Uranium and Nitric Acid Solutions
- Summary



UNCLASSIFIED

Project Goals

- Leverage Laboratory scientific strength in physical acoustics for critical international safeguards applications
- Create hardware demonstration capability for noninvasive, near real time, and low cost process monitor to capture future technology development programs
- Measure physical property data to support method applicability

UNCLASSIFIED

Slide 3

Heavy Water Production Monitoring: A New Challenge for the IAEA



Arak Heavy Water Production Facility
Girdler sulfide process + distillation



JCPOA-130 metric ton limit

UNCLASSIFIED

Slide 4

Swept-Frequency Acoustic Interferometry

SFAI (Swept-Frequency Acoustic Interferometry) is based on setting up Standing Waves and Resonances in a Fluid medium inside a cavity:

Resonance occurs when:


$$d = n \cdot (\lambda/2)$$

$$n = 1, 2, 3 \dots$$

λ = wavelength



Examples of standing wave when resonance occurs




UNCLASSIFIED

Slide 5

Swept-Frequency Acoustic Interferometry

How are fluid properties determined using swept frequency and acoustic interferences?



Sound speed = $2d\Delta f$

Sound absorption $\propto \delta f$

Δf = frequency spacing


δf = peak width

There can be hundreds of such resonance peaks in a typical spectrum

UNCLASSIFIED

Slide 6

Developed GUI (Matlab)



UNCLASSIFIED

Slide 7

Large Scatter in Literature Values





FIG. 1. Sound velocity vs temperature in \circ : pure H_2O ; \square : pure D_2O ; Δ : $(\text{H}_2\text{O})_{0.525}(\text{D}_2\text{O})_{0.475}$ solution.

Conde, J. Chem. Phys. 76(7), 1 Apr. 1982



Gupta, J. Chem. Thermodynamics 1976, 8,627

Wilson, JASA 1961, vol 33, no. 3, 314

McMillan, JASA 1947, vol 19, no. 6, 956


Literature: old data
Large scatter

D_2O purity not well known

UNCLASSIFIED

Slide 8

Large Scatter in Literature Values




Literature data at 25°C for **'pure'** D₂O show a scatter of about **5%** in concentration.

*Wilson used 99.82% D₂O

UNCLASSIFIED

Slide 9

Highest Precision Sound Speed Data Available: New Standard in H/D



!Reference data – calibration curve

We can measure accurate and precise sound speed, to the first decimal point

→ high precision/accuracy for D₂O concentration, ~ 0.1%

nuclear reactor grade:
99.75–99.98% deuterium enrichment


*precisions of ± 0.2-0.4% using other methods, gravimetric, float bath, displacement, mass spectrometry, IR Spectroscopy, emission spectroscopy, nuclear magnetic resonance, cryoscopy, refractometry, etc.)

UNCLASSIFIED

Slide 10

~400 pts of data

Calibration data taken with a Density and Sound Velocity Meter:
Anton-Paar DSA 5000 M



UNCLASSIFIED

Slide 11


Noninvasive Measurements in SFAI Cell

Lab environment



Anton-Paar



Field



UNCLASSIFIED

Slide 12

Noninvasive Measurements in SFAI Cell




UNCLASSIFIED

Slide 13

Simple Binary Mixing Rule

Mixture law: Urick model



Simple linear combination based on the volume fraction ϕ :

$$\rho = \phi \rho_D + (1 - \phi) \rho_H,$$

ρ_D - density of pure D₂O


ρ_H - density of pure H₂O

RESIDUAL PLOT!!!


UNCLASSIFIED

Simple Binary Mixing Rule

Mixture law: Urick model



Difference (Experimental – Model)




UNCLASSIFIED

Slide 15

Heavy Water – 3 Molecule System

*Hydrogen Isotope Disproportionation




Sound speed HDO ???

UNCLASSIFIED

Slide 16


Submitted a Proposal to NA241 SGTech Call



U.S. DEPARTMENT OF
ENERGY

SENSITIVITY LEVEL

Non-invasive acoustic monitoring of D₂O concentration




OFFICE OF
NONPROLIFERATION AND
ARMS CONTROL (NPAC)

INTERNATIONAL NUCLEAR SAFEGUARDS

Field portable and process monitoring solutions for heavy water verification

Background/State of the Art





- Current methods: periodic sampling or invasive continuous monitoring
- No persistent monitoring and verification
- Relatively expensive
- Needs significant user interaction
- No other entity works on acoustics approach


Approach, Metrics and Outcomes

MAIN GOAL

- Reduce inspectors presence/increase verification coverage
- Demonstrate functionality in the field on different storage forms (process pipes, drums, tank walls, etc.)

Acoustic transducers on 55 gal drum



D₂O concentration (%)

Sound speed (m/s)

HOW IT WORKS

- Determine accurate sound speed in fluid using Swept Frequency Acoustic Interferometry (SFAI).
- We already demonstrated high precision/accuracy for D₂O concentration, ~ 0.1% (relative) in laboratory.

ASSUMPTIONS, LIMITATIONS & CONSTRAINTS

- Constraints: at low temperatures (5°C), the temperature has to be measured within 0.03°C. However, at high temperatures (70°C), measurements within 0.5°C will suffice.

Impact

- Safeguards relevance
 - Current approaches do not provide noninvasive continuous monitoring and verification by the IAEA
 - CONOPS 1: man portable tool
 - CONOPS 2: continuous unattended verification
- Long-Term R&D STR-375 LTRD Capability 5/LTRD Milestone 5.6
- IAEA STR-382 Objective: SGTS-001, NDA Techniques, Objective 3
- Start of FY TRL = TRL5
- End of FY TRL (Planned) = TRL6
- End of project TRL (Planned) = TRL8

Goals/Action Plan

- **Planned tasks:**
 - 1 - Portable on-site inspection tool
 - 2 - User-friendly software interface
 - 3 - Continuous unattended monitoring
 - 4 - Field tests and technique refinement

Future FY


- Continuous unattended monitoring
- Field tests and technique refinement

Team

Los Alamos National Laboratory

PI: Cristian Pantea
pantea@lanl.gov, 505-665-7598

Innovation



Acoustic transducers on pipe

- Use acoustics and clamp-on transducers
- **Noninvasive, unattended, continuous monitoring**
- Preliminary data very promising. Sound speed sensitive to H/D content.


R&R #: 01

**SENSITIVITY LEVEL: UNCLASSIFIED
AND REVIEW & RELEASE NUMBER**


UNCLASSIFIED

Slide 17

Uranium Solution Monitoring: Inspired by IAEA Challenge in Kazakhstan



Non-Invasive Acoustic-Based Monitoring of Uranium in Solutions



The density of each solution used in the experiment was determined by pycnometric measurement to an accuracy of $\pm 0.05\%$.

The conductivities, i.e., specific conductances, of the experimental solutions were measured using a Radiometer conductivity meter (type CDM3) with a dip-type conductivity cell. The cell constant for the meter was experimentally determined to be 1.00 cm within 1.34%. This meter is equipped with temperature compensation and is capable of measuring conductances from 1.5 microsiemens to 200 millisiemens.

SUMMARY

Conductivity, density, and acidity measurements were made on a series of uranyl nitrate solutions under a number of process conditions of temperature and acidity. It has been found from this study that the acidity and conductivity of the solutions were quite sensitive to the uranium and nitrate concentration, whereas the density is sensitive only to the uranium concentration.

The complex relationships among acidity, conductivity, temperature, density, and concentration were quantified in this study. Computer programs were written to quickly predict or calculate the uranium and nitrate concentrations where (a) the temperature, density, and conductivity or (b) the temperature, density, and pH are known. The use of these programs will allow precise process control to be exercised in the preparation of HTGR recycled fuel particles by the simple monitoring of the density, temperature, and either conductivity or pH of the process solution.

UNCLASSIFIED

Slide 19

Non-Invasive Acoustic-Based Monitoring of Uranium in Solutions




Fig. 2.2. Density of nitric acid solutions as a function of molar concentration at 25°C.

For this proof-of-principle, we investigated the outlined area above.

UNCLASSIFIED

Slide 20

Non-Invasive Acoustic-Based Monitoring of Uranium in Solutions

The following solutions were prepared by Greg Wagner (C-PCS) and Marianne Wilkerson (C-DO)



1	Sample number	HNO ₃ Conc.	Sample vol	g of UO ₂ (NO ₃) ₂ ·6H ₂ O (UNH)	g DU	g dU/g UNH	DU g/l	UNH g/l
2	1	1M	24ml	0	0.0000	0.4741	0.0	0.0
3	1001	1M	24ml	2.4019	1.1387	0.4741	47.4	100.1
4	2001	1M	24ml	4.8070	2.2790	0.4741	95.0	200.3
5	3001	1M	24ml	7.2005	3.4138	0.4741	142.2	300.0
6	2	2M	24ml	0	0.0000	0.4741	0.0	0.0
7	1002	2M	24ml	2.4079	1.1416	0.4741	47.6	100.3
8	2002	2M	24ml	4.8001	2.2757	0.4741	94.8	200.0
9	3002	2M	24ml	7.2086	3.4176	0.4741	142.4	300.4
10	3	3M	24ml	0	0.0000	0.4741	0.0	0.0
11	1003	3M	24ml	2.4022	1.1389	0.4741	47.5	100.1
12	2003	3M	24ml	4.8047	2.2779	0.4741	94.9	200.2
13	3003	3M	24ml	7.2000	3.4135	0.4741	142.2	300.0
14					Total g of dU	20.4967		

UNCLASSIFIED

Slide 21

Non-Invasive Acoustic-Based Monitoring of Uranium in Solutions

1 measurement -> 2 variables
Sound speed and Attenuation




Sound speed alone does not uniquely identify U concentration

UNCLASSIFIED

Slide 22


1 measurement -> 2 variables
Sound speed and Attenuation



UNCLASSIFIED

1 measurement -> 2 variables

Sound speed and Attenuation




UNCLASSIFIED

Slide 24

Non-invasive acoustic-based monitoring of Uranium in Solutions

1 measurement -> 2 variables
Sound speed and Attenuation




UNCLASSIFIED

Slide 25

Summary

- Developed methodology for in-situ and onsite verification of D2O inventory
- New method for U process solution verification - Disruptive for process monitoring!!!
- Simple, low cost, modest electronics, easy deployable



UNCLASSIFIED