

LA-UR-18-20664

Approved for public release; distribution is unlimited.

Title: Introduction to Gamma Spec

Author(s): Rees, Brian G.

Intended for: Training for Emergency responders - including international partners

Issued: 2018-01-30

Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the Los Alamos National Security, LLC for the National Nuclear Security Administration of the U.S. Department of Energy under contract DE-AC52-06NA25396. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

Introduction to Gamma Spec

Brian Rees

Los Alamos National Laboratory

Why

Determine radiation energy levels

to

Determine materials involved

Why we care and what we care about

- Materials
- Intervening materials

How


- Radioactive decay results in discrete energy transformations that uniquely identify the materials involved
- Alpha, Beta, Gamma
- Energy is absorbed by detector, transformed to electrical signal, amplified, “binned”, and displayed, stored, etc.

What and How

Scintillators

- NaI Sodium Iodide
 - Some radiation absorbed by NaI, excites it, decays by photon emissions (wavelength, time)
 - Interacts with PMT (Photomultiplier tube)
 - Photocathode converts light to electrons
 - Multiplies 10^6 - 10^7 to form a useable pulse
- CsI Cesium Iodide

PMTs



What

Solid State Devices

- CZT Cadmium Zinc Telluride
 - Room Temp
 - Small Crystal
 - Not efficient at high energies
- HPGe High Purity Germanium
 - Cooled to LN₂ temperatures (-245° F)
 - Crystal
 - Pre-amp
 - Size does count – relative to 3"x3" NaI

What and How

Solid State Detectors

- Radiation reacts in crystal, creates ion pairs, ions swept through crystal and collected on anode and cathode
- Multiplied and collected for display, processing, etc.
- Better resolution
 - Faster
 - No translation, transmission, etc.

Comparison




Figure 2. HPGe in comparison to NaI and CZT detectors.


Issues

- Drift
- Progeny
- Shielding
- Other (radioactive) materials

ID'ing

- Calibration
- Lines
- Abundances
- Progeny
- Interferences
 - RF
 - Magnetics
 - Background
 - Fluctuates, varies


Spectra




Livetime: 242.0 sec

Deadtime: 27.98 %

Neutrons: NA





Medical Irradiator



Shipped from Canada to hospital in Boston. RIID gives incorrect identification.

24 kCi Co-60, heavily shielded.

Used for medical sterilization, blood & bone for transplants, research applications.

MDS™ Nordion™
Science Advancing Health

Gammacell®
220 Excel



Spectrum consistent with heavily shielded Co-60. The 1173 keV peak is not visible.

Radiation from wooden box with collimators was just scatter.