

LA-UR-18-23136

Approved for public release; distribution is unlimited.

Improved Hydrogen Getter Materials: FY17 Activities for the Enhanced Surveillance and Readiness Campaigns Title:

Author(s): Hubbard, Kevin Mark

Sandoval, Cynthia Wathen Ortiz-Acosta, Denisse

Moore, Tanya

Intended for: Report

Issued: 2018-04-12



Improved Hydrogen Getter Materials:

FY17 Activities for the Enhanced Surveillance and Readiness Campaigns

Kevin Hubbard and Cindy Sandoval (MST-7) Denisse Ortiz-Acosta and Tanya Moore (C-CDE)

January 30, 2018



Introduction


- Material under study is a catalyst/getter composite
 - Pd organometallic compound catalyst for H₂ dissociation
 - DEB irreversible organic hydrogen getter
- Getter composite can be infiltrated into the pore structure of open-celled foams by vapor- or solution-phase methods
 - High surface area
 - Direct contact with emitting or sensitive materials
 - Direct replacement of existing materials
- Study of manufacturing issues need to be addressed to better inform any potential decision on production




FY17 Tasks

- Vapor phase deposition:
 - Improve sublimation stability (with time) and efficiency for DEB deposition
 - Analyze volatile species present in getter/catalyst deposit
 - Effect of hydrogenation
 - Effect of UV exposure during deposition
- Solution phase deposition:
 - Evaluate:
 - Reproducibility
 - Solution aging
 - Solution re-use
 - Develop proof-of-principle concept for infiltration of multiple substrates
 - Develop a concept for recycling of toluene solvent
- Additive manufacturing of silicone/getter composites (C-CDE collaboration funded by Enhanced Surveillance, but of relevance to Readiness):
 - Examine getter performance as a function of resin composition, curing temperature, and catalyst type
 - Demonstrate printing of 3D structures (C-CDE)

Characterization







- Hydrogen uptake measurements
 - p,T vs t in a closed system
 - Not realistic conditions screening
 - Confirmed lack of reaction with pure DEB or pristine silicone
- IR spectroscopy
- Thermal analysis (DSC/TGA)
- SEM/EDS
- RBS (composition)



Vapor Deposition Process











- Cyclopentadienyl[(1,2,3-n)-1-phenyl-2-propenyl]Pd
 - Optional photolysis with UV LED (365 nm) 50 mW/cm² (aging/compatibility)
- M97xx foam sheets from KCP (1-3 mm thick)
- Forced-flow substrate configuration
- 1-2 wt% loading



DEB Deposition Rate






- Sublimation/deposition rate of DEB decreases very quickly with time
 - Difficult to control deposit composition (DEB/Pd ratio)
 - Limits film thickness
- Grain coarsening
 - Decrease in specific surface area
 - Formation of dense "cap"
- Re-condensation
 - Forms a low-density, filamentary, "trap" above the crucible


Small-Scale Solution

L.W. Fannin, D.W. Webb, and R.H. Pearce, J. Cryst. Growth 124 (1992) 307



- Blend DEB with SiC grit
 - DEB present in "interstitial" volume
 - Limits grain coarsening
- Added a supplementary ring-shaped heater near the crucible rim
- Work in FY16 demonstrated reasonable success using a small (1cc) source
 - Uniform deposition rate
 - Little re-condensation at crucible lip

Large-Scale Solution Attempt




- For FY17 it was attempted to implement this solution using a larger DEB source with a 10cc crucible necessary to enable deposition over larger surface area and/or multiple substrates
 - SiC grit
 - Glass beads of various sizes (1-3 mm)
- This approach was not successful for the larger source
- Deposition rate still decreases quickly with time



UNCLASSIFIED

Deposition Efficiency




- Also, sublimation efficiency is quite low and is made worse by use of the grit/beads
- Reasonable coating thickness can actually still be obtained with the larger 10cc source, at least for small substrates
- However the process is very wasteful of DEB material recovered from the crucible can probably not be reused because of grain coarsening that would reduce sublimation rate



Analysis of Volatile Species


- Getter samples produced by vapor-phase infiltration clearly contain volatile organic species
- May be an issue with respect to long-term aging and compatibility
- Attempt to identify species using an RGA
 - Phenylpropenyl-based
 - Cyclopentadienyl-based
- Effect of UV exposure during infiltration
 - 25 mW/cm² directed through cp-Pd-pp vapor plume








Volatile Species – Time Dependence



- Data indicate that much of the volatile species are significantly depleted over a period of days
 - Exception is 115-118 amu phenylpropenyl-based species
 - Only two data points, so a "half-life" was not determined




Volatile Species – Composition



- Phenylpropenyl-based species can clearly be identified
 - Remains largely intact during the deposition process
 - Incorporated into the growing film, either still bound to Pd or otherwise
- Cyclopentadiene-based species are not clearly identified
- Most of the peaks can not be clearly associated with either of the two ligands
 - Significant fragmentation, reaction of the Cp ligand

Volatile Species – Effect of UV Exposure



- Exposing the cp-Pd-pp vapor plume to UV during exposure has no effect on the volatile species present in the deposit
 - UV does not induce additional fragmentation/reaction of the precursor
 - Flux or photon energy too low??
 - May require sustained illumination of the substrate not practical for a production system




Vapor Infiltration - Summary


- Grain coarsening causes the sublimation/deposition rate of DEB to decrease quickly with time
 - A solution adopted from the semiconductor industry was effective for a small DEB source, but not for the larger source that would be needed to infiltrate larger and/or multiple substrates
- However, deposition of the Pd precursor also decreases with time (due to decomposition of the compound in the source), so that the variation in deposit composition with time is manageable
 - Both sources were therefore be used as-is in order to continue evaluation of the effects of UV exposure during deposition, and to analyze volatile species in the deposit
- Volatile species from the getter deposit were readily detected and analyzed
- Phenylpropenyl-based species can be identified
 - This ligand largely remains intact during deposition and is relatively non-volatile
 - It is deposited in the growing film, either still weakly bound to the Pd or in isolation
- Cyclopentadienyl-based species are not identified, and....
- Most of the observed species can not be specifically associated with either of the two ligands present in the original precursor
 - The Cp ligands may have largely fragmented/reacted during deposition and been deposited as a relatively volatile mix of organic species in the growing film
 - The concentration of this organic mix (but not of the phenylpropenyl species) decreases noticeably over a period of days, but a "half-life" was not determined



Solution Deposition Process


- Eliminate complex vacuum system
- More uniform infiltration
- Higher loading
- DEB
- Bis(dibenylidenenacetone)Pd(0)
- Toluene
 - Good solubility intimate mixing
 - Swelling ratio = 1.3 (Lee et al., Anal. Chem. 75 (2003) 6544)
 - Ability to infiltrate at a molecular level
 - Slight (~10%) degradation in mechanical properties
- Mix solution
- Immerse M9747 foam for 24 hours
- Remove foam and evaporate solvent (ambient)
- 3-8 wt% loading









Toluene/Silicone Interaction





- Toluene extracts unpolymerized monomer from the M9747 silicone foam
 - Resulting mass loss makes it difficult to quantify getter loading
- It is necessary to measure the foam mass loss in *pure* toluene so that getter loading can be accurately determined by measuring foam mass before/after infiltration
 - Average mass loss is 1.56 ± 0.05 wt% for 24 hour immersion
 - Mass loss decreases slightly as toluene is re-used
 - Is toluene starting to become saturated?

Process Reproducibility - Loading





- Loading of 3.06 wt% nominally provides a capacity of 0.038 mole $H_2 = 0.84 L H_2$ per 100 grams of foam
- Previous experiments show loading can be easily increased by increasing solution concentration or foam specific surface area

- Nine samples were prepared from nine nominally identical solutions
 - Average loading is 3.06 ± 0.24 wt%
 - Sample-to-sample variation is greater than the uncertainty in the loading measurement
 - Will be necessary to define an acceptable range
- Infiltration nominally consumed 3.7 ± 0.4 wt% of the precursor from solution
 - Limits potential solution re-use
 - Could be reduced by increasing the ratio of solution volume to sample size, though this would increase solvent usage




Process Reproducibility - Performance





- Hydrogenation of the infiltrated samples was measured as a function of time
- Three sets of three samples each to improve S/N
 - Data show very good reproducibility
 - Reaction extent confirms hydrogenation of the Pd(dba)₂ precursor
 - Overall reaction proceeds to $80 \pm 3\%$ assuming DEB and Pd(dba)₂ are deposited and hydrogenated with equal efficiency


Solution Aging - Loading



- Nine jars of nominally identical solution were prepared and aged for four weeks - ambient temperature with magnetic stirring
- Nine foam samples were infiltrated using the aged solution
 - Pristine: 3.06 ± 0.24 wt%
 - Aged: 4.56 ± 0.34 wt%
- Significant *increase* in loading!




Solution Aging - Performance




- Hydrogenation data were obtained as a function of time for samples prepared from pristine and aged solutions
- Consumption data normalized to getter content (fractional getter consumption) indicate significant differences in deposit properties
 - Morphology, composition, chemistry...

Solution Aging – Deposit Structure

Pristine solution






Aged solution



- Deposits prepared from the aged solution show a high concentration of micron-scale nodules
- It is speculated that these modules are, or contain, metallic Pd
- Pd(dba)₂ is known to gradually (days-weeks) decompose in toluene to form Pd nano/micro-particles and free dba ligand
 - Consistent with solution color change from red/purple to black
- Resulting variations in particle concentration and solution composition would alter the deposit characteristics and could account for the observed changes in loading and performance

Solution Re-Use - Loading




Sample Set

2.5

- Five jars of nominally identical solution were prepared
- Three sets of five samples each were prepared on successive days
 - Minimizes effects of solution aging
- Loading was found to progressively decrease from set-to-set
 - $3.35 \rightarrow 2.69 \rightarrow 2.44 \text{ wt}\%$
 - Especially for sets 1 and 2, the difference is much greater than can be accounted for by the depletion of precursor in the solutions.
 - Note that sample-to-sample variation also decreases progressively

2.0


Solution Re-Use - Performance




- Hydrogenation data for the samples was measured as a function of time
 - All five samples from a given set were measured simultaneously to improve S/N
- Significant variations are again observed when the hydrogen consumption data are normalized to getter content
 - Significant differences in deposit properties
 - Morphology, composition, chemistry...

Solution Re-Use - Structure

Set 1






- The first sample set shows a relatively high concentration of Pd nodules in the deposit
- Published data show that commercial Pd(dba)₂ actually contains varying concentrations of Pd nano/micro-particles *even in the as-received state*
- These particles appear to be deposited with high efficiency relative to molecular species
 - They are therefore depleted from solution after preparation of the first sample set
- Resulting changes in deposit properties can account for (along with depletion of the precursors from solution) the observed set-to-set differences in loading and performance




Proof-of-Principle Solution Infiltration System - I



- A proof-of-principle system was designed for infiltrating multiple foam substrates
 - A primary goal is to minimize the ratio of solution volume to substrate volume as much as feasible (waste minimization)
 - Magnetic stirring of solution at the desired frequency
 - Rotation or counter-rotation of substrate holder at the desired frequency
 - The design can easily be generalized to a variety of substrate shapes and sizes

Prototype Solution Infiltration System - II



- The substrate holder can be placed into a vacuum drying chamber to quickly remove toluene once the infiltration is complete
- Used solutions can be treated in a Rotovap to recover and recycle the toluene, reducing the environmental footprint of the operation






Solution Infiltration Summary

- The toluene solvent extracts un-polymerized monomer from silicone foams the resulting mass loss was quantified to enable accurate determination of the getter loading
- The infiltration process appears to be adequately reproducible
- Solution shelf life may be limited Pd(dba)₂ appears to decompose in toluene to Pd particles and free dba alters deposit characteristics and effective getter capacity
- Solution re-use may (depending on solution concentration) be limited by depletion of the getter/catalysts compounds from solution during infiltration
 - Any Pd particles in the as-received Pd(dba)₂ will introduce additional run-to-run variability
- A spec must be developed for the acceptable range of getter loading and effective hydrogen capacity per mass of foam
- Proof-of-principle hardware has been designed for infiltrating multiple substrates
- A Rotovap has been purchased to demonstrate recovery of toluene from used solution, enabling recycling of the solvent and reduced waste disposal




Additive Manufacturing - Concept




- Project to AM precise and reproducible foam structures from silicone/getter composite resins
- Funded through Enhanced Surveillance WP
- Collaboration with Denisse Ortiz-Acosta of C-CDE, who is the project lead
- Work is relevant to Readiness as well
- Primary MST-7 responsibility is to characterize the performance of composite resins in both cast and printed forms
- Experiments have so far been primarily based on Sylgard 184 resin loaded with 4.0-4.3 wt% DEB plus Pd/C or Pd(dba)₂ as catalyst




Effect of Curing Temperature






- Silicone/getter composites are capable of excellent performance
 - Diffusion of hydrogen through the silicone matrix is not a major constraint
- High cure temperature is desired for AM in order to shorten cure time
 - Reduce part deformation and enable smaller feature size
- However, increasing cure temperature is found to dramatically reduce the effective hydrogen capacity and, especially at higher values, the reaction rate
 - $T_{cure} = 75$ °C was found to provide an acceptable compromise

Effect of Cure Agent Concentration






- At fixed T_{cure}, an increase in cure agent concentration is also found to dramatically degrade getter performance
- Suggests reaction between DEB and a component of the cure agent during the cure process, decreasing the concentration of active getter sites
 - Confirmed by NMR measurements
- It is thought that reaction occurs with the methylhydrogen siloxane component of the cure agent
 - Nominal concentration is 2-3 wt%
 - Comparable to DEB concentration




Effect on Mechanical Properties




- Reaction between methylhydrogen siloxane and DEB during curing reduces the crosslink density of the cured sample
- This in turn causes a significant degradation of the mechanical properties
- The degradation may or may not be important depending on the application

Cast vs. Printed Samples




- Silicone/getter composite resins have been successfully printed
- The effective hydrogen capacity of the printed samples is essentially equal to that of cast samples
 - No deleterious effects caused by the printing process
- Initial reaction rate is higher for the printed samples
 - Higher specific surface area


Effect of DEB Concentration



- Preliminary experiments on cast samples demonstrate that the hydrogen capacity of the composite can be effectively increased by increasing the DEB/Pd/C concentration
- Loss of capacity caused by the reaction of DEB during curing can be easily recovered
- Printing has not yet been demonstrated changes to resin rheology may have an influence but can be accounted for by adjusting inert filler concentration

Effect of Catalyst






- Composite resins were also prepared using Pd(dba)₂ as the catalyst
 - Solution blending with toluene
 - More uniform dispersion of catalyst and getter
 - Fewer large aggregates in the resin
 - Less clogging of printer nozzle
 - Finer feature size
- Performance of Pd(dba)₂ is essentially equivalent to that of Pd/C
- AM printing of this resin has been demonstrated




Solution Infiltration of AM Samples

- Back-up process in case printing a Sylgard/ getter composite resin was not possible
- Maintain benefits of precision AM structure
- Substrates (three in each set)
 - AM Sylgard 184 mesh
 - Cast Sylgard 184 sheet (2 mm thick)
- Solution #1
 - 2.40e-2 M DEB
 - 4.67e-3 M Pd(dba)₂
 - Mole ratio DEB/Pd(dba) $_2 = 5.14$
- Material completely infiltrated 2 mm thick cast sample – aided by swelling of silicone matrix by the toluene solvent

- Samples from Set #1 appears red/purple the color of Pd(dba)₂ → Did DEB successfully infiltrate as well?
 - Additional samples with only Pd(dba)₂
 prepared as a test (compare performance with nominal DEB + Pd(dba)₂)
- Solution #2
 - 4.67e-3 M Pd(dba)₂
- Solution #3
 - 1.40e-2 M Pd(dba)₂



Infiltrated AM Samples - Performance



- Extrapolated reaction extent for DEB/Pd(dba)₂ is 9.81e-5 mole H₂/g sample
- Corresponding value for Set #2 is \sim 2-3e-5 mole H₂/g sample
 - Both DEB and Pd(dba)₂ are infiltrated with more or less comparable efficiency
- Set #3 shows relatively little gain in performance
 - Pd(dba)₂ infiltration appears to reach a saturation point
- Printed samples with KCP material hydrogenate 3.81e-4 mole H_2/g sample (3.9x better)
- Because printing of the composite resin has been demonstrated, this is not likely to be a needed alternative process

AM Summary

- Silicone + DEB/Pd/C composites act as effective getter materials diffusion of hydrogen through the silicone is not a significant limitation
- DEB reacts with methylhydrogen-siloxane in the cure agent during curing, consuming an increasing fraction of getter sites as T_{cure} is increased
- This reaction also reduces crosslinking during cure, degrading mechanical properties
 - $T_{cure} = 75$ °C represents a suitable compromise
- Getter capacity can be improved by increasing the DEB/Pd/C concentration in the resin
- AM printing of 3D mesh structures from the composite resin has been demonstrated
- Use of Pd(dba)₂ as catalyst decreases the size of aggregates in the resin, reducing nozzle clogging and enabling smaller feature size, and has also been demonstrated
- AM structures prepared from silicone only can be treated by solution infiltration of DEB/Pd(dba)₂, but the loading is considerably less than AM samples prepared from the silicone/DEB/Pd/C composite resin



Proposed Future Work

Vapor infiltration

- This method presents a number of serious difficulties with respect to scaled-up production
- Overall performance is not as good as materials produced by solution infiltration
- Unless otherwise directed, future work will focus on the solution method

Solution Infiltration

- Attempt to improve the aging and re-use characteristics of the solution with respect to the Pd precursor compound
 - Obtain a better understanding of how Pd(dba)₂ ages/decomposes as a function of time in toluene
 - Evaluate modifications to Pd(dba), to enhance stability and infiltration reproducibility
 - Evaluate the use of alternative precursors such as Pd(acac)2, which may be more stable in toluene
- Assemble a prototype system to enable processing multiple parts
- Assemble a closed solvent evaporation system to enable capture/recycling of evaporated solvent

Additive manufacturing (C-CDE collaboration funded by Enhanced Surveillance)

- Evaluate alternate matrix polymers
- Evaluate alternate getter compounds, including a matrix polymer functionalized with getter sites

