

LA-UR-18-25919

Approved for public release; distribution is unlimited.

Title: Radiation Survey Instrumentation

Author(s): Mclean, Thomas Donaldson

Intended for: Training

Issued: 2018-07-03

Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the Los Alamos National Security, LLC for the National Nuclear Security Administration of the U.S. Department of Energy under contract DE-AC52-06NA25396. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.



Radiation Survey Instrumentation

DOE-HDBK-1122-2009

Module 2.16

Tom McLean

Los Alamos National Lab

Alcorn State University

July 2018



Operated by Los Alamos National Security, LLC for the U.S. Department of Energy's NNSA

Agenda

July 2018

Alcorn State University
Lorman, MS



- **Objectives:**
- **2.16.01: Factors affecting instrument selection of appropriate instrument for external surveys**
- **2.16.02: Features and specifications (F&S) for ion chambers**
- **2.16.03 F&S for high-rate instruments**
- **2.16.04 F&S for neutron detection and measurement**

Introduction: class discussion

What is purpose or goal of external radiation surveys ?

What type of type of radiation fields are of interest in external surveys ?

What sort of facilities or operations would external surveys be of potential interest ?

Introduction:

- **External radiation control measurements and accurate postings are dependent on accurate measurements of external dose and exposure**
- **Reliant on the appropriate instrument for the particular survey**
 - Based on type, energy and activity of the radiation
 - Correct use and operation of the instrument (training !)
 - Calibration of the instrument in a known field approximating the conditions during the survey (how likely is this ?)
 - Conditions such as:
 - background levels
 - presence of interfering radiation
 - pulsed fields (e.g. accelerators or neutron generators)
 - environmental conditions (e.g. temperature, humidity, RF fields, magnetic fields)
 - Requirements as specified in Procedures

2.16.01: Instrument selection considerations

- **Quantity to be measured:**

- For exposure measurements an ion chamber is best choice
 - Relatively flat energy response
 - Also suitable for beta absorbed dose measurements (beta shield open) but correction factor is required
 - Vented chambers suitable for fields > 1 mrem/h but also susceptible to temperature and humidity effects
 - Pressurized (sealed) ion chambers suitable for exposure levels near background levels
- For gamma dose equivalent measurements
 - Plastic scintillators have excellent tissue equivalence (e.g. Bicron micro-rem meter)
 - Energy compensated GMs (hot dog probes)
 - NaI-based probes are highly sensitive but very poor tissue equivalency
 - Ion chambers often used as well ($1R \sim 1rem$)
 - In high fields (>5 R/h or rem/h), the use of teletectors (GM-based) best conforms to the principles of ALARA

2.16.01: Instrument selection considerations

- **Quantity to be measured:**

- For neutron dose measurements a rem ball is the most common choice
 - Provides continuous coverage across wide range of neutron energies
 - Gamma insensitive
 - But heavy (>20lb) and can lead to ergonomic injuries
 - Other options exist including a lighter weight version (7" diameter as opposed to 9" diameter polyethylene sphere)



2.16.01: Pre-operational checks

- **Generally specified in the relevant instrument operating procedure. But typically includes several of the following:**
 - Check for any obvious signs of damage (dents, rattling, loose knobs, etc...)
 - Verify calibration is valid i.e. not past due
 - Check battery level indicator and change if required
 - If applicable, zero the display (e.g. ion chambers)
 - Do a source response check and compare to past checks
 - Verify location of effective center (look for markings)
 - Can be important when making contact measurements and in comparing readings taken by different instruments
 - Others ?

2.16.01: Other instrument selection criteria

- **Are beta and/or low energy gamma measurements of interest ?**
 - Consider instrument shielding (housing) and entrance window thickness
 - Consider use of an instrument with a beta shield
 - Be aware that correction factor required for beta absorbed dose measurement when instrument calibrated for gamma dose or exposure.
 - Also difficult to distinguish between betas and low energy gamma or x-ray photons.
- **Is the instrument appropriate for the task at hand?**
 - Check vendor's specs on energy range covered by instrument
 - Check vendor's specs on dose rate limits

2.16.01: Additional comments

- **Instruments designed for external measurements are calibrated in terms of dose or exposure rate**
 - Readout units in terms of mrem/h, μ R/h, R/h, etc
 - Displays can be analog or digital
 - Be aware of geotropism with analog meters
 - Displays can be auto-scaling or require user to switch manually
 - Be aware that auto-scaling may go un-noticed
- **Remember that instruments are calibrated while fully irradiated in reference field**
 - If instrument is only partially illuminated then correction factors are likely required
 - For example, an ion chamber used to measure streaming through a shield wall

2.16.02: Ion chamber instruments

- **Designed to measure exposure or air kerma (dose)**
 - A rate meter measurement is often the only operating mode option
- **Vented ion chambers use air as detector medium**
 - Readings dependent on ambient temperature and barometric pressure
- **Pressurized ion chambers for environmental-level measurements**
 - N_2 and Ar gas commonly used
 - Pressures up to 24 atm.

2.16.02: Ion chamber instruments

Vendor/Model: Thermo RO20

Type: Ion chamber

Radiation detected: Gamma and beta

Dimensions: 7.9" x 4.2" x 7.7"

Weight: 1.6 kg

Active volume: 220 cm³

Interferences:

Energy response: Excellent

Energy range: 8keV-1.3 MeV window open, 30 keV- 1.3 MeV closed

Dose rate range: 0.1 mR/h – 50 R/h

Sensitivity: ~ 25 pA per R/h

Beta shield: Yes, 7 mg/cm²

Response time: 10-90% within 5s

Temperature limits: -40°C to 80°C

Bias voltage: 36v

Comments:



2.16.02: GM instruments

Vendor/Model: Thermo HP270

Type: Energy compensated “hot dog” GM

Radiation detected: Gamma and beta

Dimensions: 6.0” x 1.5” diameter

Weight: 0.14 kg

Active volume: 14 cm³

Interferences:

Energy response: Good

Energy range: 30 keV- 1.3 MeV closed

Dose rate range: 0.020 mR/h – 3 R/h

Sensitivity: 1200 cpm/ (mR/h)

Beta shield: Yes, 30 mg/cm²

Dead time: 100 μs

Temperature limits: -40°C to 75°C

Bias voltage: 900v

Comments: Needs rate meter



2.16.02: GM instruments

Vendor/Model: Mirion BAK-2283

Type: Energy compensated teletector GM (2)

Radiation detected: Gamma and beta

Dimensions: 11' long when extended

Weight: 2.0 kg

Active volume: ~10 cm³

Interferences: Beta (high-energy)

Energy response: Good (+/- 25%)

Energy range: 50 keV- 2.0 MeV

Dose rate range: 0.020 mR/h – 1.5 R/h

Sensitivity: 1080 cpm/ (mR/h)

Beta shield: No

Dead time: 50μs

Temperature limits: -20°C to 50°C

Bias voltage: 900v

Comments: Needs rate meter



2.16.02: Scintillator instruments

Vendor/Model: Ludlum 44-10

Type: NaI(Tl) 2"x2"

Radiation detected: Gamma

Dimensions: 11.0" x 2.6" diameter

Weight: 1.04 kg

Active volume: 102 cm³

Interferences: Beta

Energy response: Poor

Energy range: 50 keV - 3 MeV

Dose rate range: background to 3 mrem/h

Sensitivity: 900 cpm/ (μR/h)

Beta shield: No

Response time: dependent on rate meter setting

Temperature limits: -40°C to 75°C

Bias voltage: 500-2000v dependent on PMT

Comments: Needs rate meter



2.16.02: Scintillator instruments

Vendor/Model: Thermo SPA3

Type: NaI(Tl) 2"x2" scintillator

Radiation detected: Gamma

Dimensions: 11.0" x 2.6" diameter

Weight: 1.5 kg

Active volume: 102 cm³

Interferences: Beta

Energy response: Poor

Energy range: 60 keV - 3 MeV

Dose rate range: background to 3 mrem/h

Sensitivity: 1200 cpm/ (μR/h)

Beta shield: No

Response time: dependent on rate meter setting

Temperature limits: -30°C to 60°C

Bias voltage: 500-2000v dependent on PMT

Comments: Needs rate meter



2.16.02: Scintillator instruments

Vendor/Model: Bubble Technology Industries, Microspec-2 E probe

Type: NaI(Tl) 2"x2" scintillator

Radiation detected: Gamma

Dimensions: 6.0" x 3.6" x 10"

Weight: 1.4 kg (probe), 1.9kg (analyzer unit)

Active volume: 102 cm²

Interferences: Beta

Energy response: Very good (spectroscopy-based)

Energy range: 60 keV - 3 MeV

Dose rate range: background to 3 mrem/h

Sensitivity: 1000 cpm/ (μR/h)


Beta shield: No

Response time: dependent on rate meter setting

Temperature limits: -30°C to 60°C

Bias voltage: 500-2000v dependent on PMT

Comments: Needs dedicated analyzer unit



2.16.03: Neutron instrument

Vendor/Model: Ludlum 12-4

Type: rem ball (2 atm. ^3He tube)

Radiation detected: Neutron

Dimensions: 9" diameter polyethylene sphere

Weight: 8.3kg (18.3 lb) with rate meter

Active volume: 1.6cm x 2.5cm tube

Interferences: none

Energy response: Fair

Energy range: 1×10^{-8} – 12 MeV

Dose rate range: up to 10 rem/h

Sensitivity: 100 cpm/ (mrem/h)

Beta shield: No

Response time: dependent on rate meter setting

Temperature limits: -20°C to 50°C

Bias voltage: 1200v

Comments: Needs rate meter



Questions ?