

LA-UR-19-22968

Approved for public release; distribution is unlimited.

Title: Radiation Detection Theory

Author(s): Duncan, Victoria Stephanie

Intended for: Training Presentation

Issued: 2019-04-02

Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by Triad National Security, LLC for the National Nuclear Security Administration of U.S. Department of Energy under contract 89233218CNA000001. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.



Radiation Detection Theory





Lesson Objectives

1. Identify **four types** of radiation detectors
2. Explain the **operational theory** of each detector
3. Identify the **types of radiation** each detector detects
4. Identify each detector's **dose rate range**
5. Identify the **advantages and disadvantages** of each detector





Agenda

- Gas Filled Detectors
- Scintillators
- Semiconductors
- Isotope Identification






Detector Types

- **Gas Filled**
 - Ion Chamber
 - Proportional Counter (Neutrons!)
 - GM
- **Scintillator**
 - NaI
 - CsI
 - ZnS
- **Semiconductor**
 - HPGe






Gas Filled Detectors





Gas Filled Detectors (cont'd)





Ion Chamber

- No gas amplification
- Good accuracy
- Drop in sensitivity below 50-100 keV photons





Fluke 451B


- **Non-pressurized**
- **Dose rate range: 0-500 mSv/hr**
- **Radiation detected:**
 - Alpha > 7 MeV
 - Beta > 100 keV
 - Gamma > 7 keV
- **Accuracy: +/- 10% for Cs-137**





Proportional Counter


- Gas amplification occurs
- Charges collected are proportional to incident energy
- Can differentiate between radiation types
- RF is difficult to shield





Proportional Counter (cont'd)

- Neutrons don't interact readily with all gases
- ^3He




- **Advantages:** High efficiency, ruggedness
- **Disadvantages:** DOT shipping issues, RF and gamma interference






Proportional Counter (cont'd)





Geiger-Mueller Tube


- Geiger discharge



- Very high dead time
- Can paralyze in high radiation fields
- Primarily used for dosimetry applications



Scintillators




- **Ideal scintillation material characteristics**
 - High light output
 - Short decay time
 - Ability to be manufactured into usable sizes





Photomultiplier Tube





Photomultiplier Tube

- **Advantages:** Large area, good noise characteristics
- **Disadvantages:** Ruggedness issues





CsI (TI) vs NaI (TI)

- **CsI (TI)**
 - High light output, long decay time
 - Expensive
 - Slightly hygroscopic
 - 8% energy resolution
- **NaI (TI)**
 - High light output, short decay time
 - Inexpensive
 - Hygroscopic
 - 7% energy resolution





HRM

- **CsI Scintillator and He-3 Proportional Counter**
- **Dose rate range**
 - Standard: 0-120 $\mu\text{Sv/hr}$
 - High Range: 120 $\mu\text{Sv/hr}$ -880 mSv/hr
- **Radiation detected**
 - Neutrons
 - Gamma > 45 keV





IdentiFINDER


- **Scintillator, He-3 Proportional Counter, and GM tube for higher dose rates**
- **Dose rate range**
 - Scintillator: 0-250 $\mu\text{Sv/hr}$
 - GM Tube: 0-10 mSv/hr
- **Radiation detected**
 - Neutrons
 - Gamma: 20 keV-3 MeV (claimed)





ZnS (Ag)

- Used for alpha detection
- Very low light conversion efficiency for fast electrons
- Opaque crystalline powder
 - Limits use to thin screens





FH-40 Alpha/Beta Probe


- **Efficiency**
 - Alpha (Am-241): 36%
 - Beta (Co-60): 23%
 - Beta (Sr-90): 49%





Semiconductors

- Require much less energy to produce charge carriers than scintillators
 - ~ 3 eV vs ~ 33 eV





HPGe

- **Great energy resolution**
- **Must be cooled**
 - Liquid Nitrogen or mechanically cooled
 - Adds size and weight
 - Can be allowed to warm to room temperature between uses





ORTEC Detective


- **HPGe, He-3 Proportional Counter, GM tube**
- **Dose Rate Range**
 - HPGe: 0-20 $\mu\text{Sv/hr}$
 - GM Tube: 0-10 Sv/hr
- **Radiation Detected**
 - Neutron
 - Gamma





Isotope Identification

- Each isotope has a “finger print” of emissions
- Exceptions
 - Pure Beta Emitters
 - Positron Emitters
 - Neutron Emitters
- Solid state detectors build a spectrum as they collect





Spectrum Collection


1. An interaction occurs in the detector head
2. That interaction is converted into a pulse proportional to the energy
3. The Multi Channel Analyzer bins this information
4. Peaks are forms for analysis





Energy Resolution



- Measure of energy peaks
- Full-width at half-maximum
- Peaks must be at least 1 FWHM apart to distinguish





Energy Resolution (cont'd)



- Comparison between NaI and LaBr_3





Spectrum Noise

- Interactions with surrounding materials and the detection medium create noise





Lesson Summary

- Four Detector Types: Ion Chamber, Proportional Counter, Scintillator, Semiconductor
- Know your instrument
 - Range
 - Advantages
 - Limitations
- Isotope Identification
 - Resolution
 - Spectrum features





Questions?

