

## LA-UR-19-24895

Approved for public release; distribution is unlimited.

Title: RH-72B Packaging Plan Slides for University of Washington

Author(s): Cocina, Frank G. Jr.

Intended for: Informational slides for University of Washington Removal

Issued: 2019-05-28

---

**Disclaimer:**


Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by Triad National Security, LLC for the National Nuclear Security Administration of U.S. Department of Energy under contract 89233218CNA000001. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

RH-72B Packaging Plan Slides for University of  
Washington  
Los Alamos National Laboratory  
Frank Cocina  
NEN-3  
5-28-2019

## Shipping Package RH-72B

Why the RH-72B container...

- Sources contain large amounts of radiation must be shipped in specialized containers that are designed to contain these materials.
- The RH-72B is a US NRC Compliant Type B Shipping Container designed for these type of radioactive materials in higher activities.
- Has been used for over 900 shipments from National Laboratories to disposal locations.



RH-72B



### RH-72B Features

- Cask is a cylinder, dimensions are 12ft Long x 3.5 ft in diameter
- The cylinder fits into two circular impact limiters to protect the cask in the event of an accident.
- Lead shielding for gamma radiation.
- External thermal shield protects the cask from potential fire damage.
- The cask is leak tight.
- All these feature are to ensure that in the event of an accident, radiation and radioactive material will remain contained within the cask.

## RH 72B Packaging Configuration


For the shipment from University of Washington

1. Breached source will remain in the Transfer Shield that is was placed into the night of the incident.
2. The Transfer shield will be placed into a “cribbing” currently being designed specifically for the transfer shield that will add additional shielding as well as ensure the transfer shield remains stationary during transport.
3. Employing a Mobile Loading Unit (MLU), the “cribbing” will be place into a Removable Top Container (RLC), an inner container designed for use within the RH-72B.
4. The MLU will then load the RLC into the RH-72B and the RH-72B will be secured to the shipping Trailer.
5. The loaded RH-72B will be shipped to its final destination at Pacific Northwest National Laboratory (PNNL)


1.




2.



3.




4.



5.



## Placement of 72B for Loading



Mobile Loading  
Unit Equipment  
Trailer Parking

Location of  
MLU for loading  
of the RLC and  
RH-72B

Location of Crane to be  
used to load the RLC and  
RH-72B

Current location of the  
Transfer Shield