

LA-UR-20-20074

Approved for public release; distribution is unlimited.

Title: Analysis of Fuel Cycle Materials for Nuclear Forensics: Pre- and

Post-detonation

Author(s): Dorhout, Jacquelyn Marie

Intended for: Seminar presentation for an interview at ORNL

Issued: 2020-01-06





Analysis of Fuel Cycle Materials for Nuclear Forensics: Pre- and Post-detonation

Jacquelyn M. Dorhout, Ph.D. ORNL January 9, 2020





Outline

- Introduction
- Background
- Pre-detonation nuclear forensics
- Post-detonation nuclear forensics





Introduction

- B.S. Chemistry from UMass Amherst
 - Bio-inorganic synthesis
- 2010 Radiochemistry Fuel Cycle Summer School at UNLV
 - Radiochemistry course with an emphasis on the nuclear fuel cycle
- 2011 ACS Summer School in Nuclear and Radiochemistry
 - Brookhaven National Lab
 - Focus on nuclear medicine and nuclear fuel

- Ph.D. from UNLV in Radiochemistry
 - Dr. Ken Czerwinski
 - Synthetic actinide chemistry
 - Nuclear forensics
- At LANL since 2014
 - Dr. Jaqueline Kiplinger
 - Organoactinide synthesis
 - Air sensitive materials, glove-box work





Introduction

- Postdoctoral Work
 - Dr. Marianne Wilkerson
 - Analysis of fuel precursors
 - Dr. Sam Clegg
 - Gas FTIR analysis of stable isotopes of nitrogen
 - Dr. Keri Campbell and Dan Kelly
 - Uranium corrosion

- Funding
 - DHS NTNFC
 - LANL LDRD

- Large groups (>15 people)
- Small groups (<5 people)
- Mentor to high-school student





Background – Nuclear Forensics

- Nuclear forensics the evaluation of signatures to determine the identification and provenance of nuclear material
 - Device, precursor materials, fuel, isotopic signatures




Part 1 – Pre-Detonation Forensics





Pre-Detonation Forensics

 Ammonium diuranate (ADU) and ammonium uranyl carbonate (AUC) are both present in multiple steps of the fuel cycle






ADU – Ammonium Diuranate

 $UO_2^{2+} + NH_4OH + HNO_3 \rightarrow UO_3 \cdot zNH_3 \cdot xH_2O + NH_4NO_3$

STIR RATE (RPM)	[U] (MG/ML)	FINAL PH	FLOW RATE (ML/MIN)	TEMP (°C)
170	50	5	2.5	21.5
280	100	8	5	35
400	200	11	7.5	50

Statistical methods were used to go from 120 possible combinations to 22 experiments that would give the most diverse data set






ADU Characterization – Color



The Munsell Color Chart was used to define the colors of each compound based on hue (color), value (lightness), and chroma (purity).



Dorhout, et.al 2020 JNM, Submitted.







ADU Characterization - pXRD

- Powder XRD was used to identify the phases present in the materials
- One uranium containing phase: UO₃·zNH₃·xH₂O
 (ICDD PDF No. 00-014-0340)
- Majority of compounds also show NH₄NO₃ (asterisks)
- Only two compounds, 3 and 16, did not contain NH₄NO₃ by XRD

Dorhout, et.al 2020 JNM, Submitted.



ADU Characterization – TGA/DSC



- TGA (green) shows weight loss as a function of temperature
- DSC (blue) shows endo- and exothermal events


Dorhout, et.al 2020 JNM, Submitted.





WEIGHT LOSS OF COMPOUND # NH₄NO₃ (%) 9.82 19.00 4.90 19.41 35.39 5 28.22 11.94 26.01 28.77 9 10 21.53 11 17.41 12 21.24 13 26.12 12.09 14 15 18.72 16 4.88 17 20.70 18 20.40 19 30.86 23.11 20 17.68 22 25.02

ADU Characterization – TGA/DSC



Dorhout, et.al 2020 JNM, Submitted.



ADU Characterization – TGA/DSC

- Appears to be a correlation between the amount of NH₄NO₃ present and the color of the compound
- Light-colored compounds had high stir rates and often high concentrations of uranium
- Dark-colored compounds has high pH (i.e. more NH₄OH added) and low stir rates or uranium concentrations





ADU Characterization - SEM Analysis

Compound 1 had one of the lowest concentrations of NH₄NO₃ (9.82 %)

Compounds 5 and 9 had some of the highest concentrations of NH₄NO₃ (35.39 and 28.77 %)


Compounds 7 and 12 were middle of the road (11.94 and 21.24 %)






ADU Characterization – Particle Size

COMPOUND	MEDIAN DIAM. (UM) LIGHT-SCATTER	MEAN DIAM. (UM) LIGHT- SCATTER
1	4.834	4.741
2	3.746	3.818
3	2.2096	2.5062
4	2.6634	2.7756
5	2.1327	2.5772
6	8.1335	8.8301
7	4.3511	5.42
8	8.1135	8.513
9	11.867	12.657
10	3.7846	3.5019
11	1.5347	2.0429
12	3.7554	4.2099
13	2.8813	3.1654
14	2.5918	2.721
15	5.7682	5.8666
16	2.7171	2.6922
17	2.6574	2.6791
18	4.134	4.3449
19	4.923	5.338
20	2.698	2.677
21	3.153	3.163
22	2.975	3.017



Compound 7



- In general, lighter colored compounds (4, 11, 16) have smaller particle sizes
- Darker compounds (9, 19) are larger
- Caveat each sample was ground with a mortar and pestle prior to analysis

\SSIFIED




ADU Characterization - MAMA

 Morphological Analysis for Materials Attribution (MAMA) is a software designed at LANL for the purposes of analyzing morphological features of materials in SEM images

MAMA measures 14 attributes, including pixel area, circularity, and ellipse

aspect ratio







ADU Characterization - MAMA

 Compounds 1-18 were analyzed and the data was used to build a model to predict MAMA results for Compounds 19-22

COMPOUND #	19	20	21	22
AVG. MINOR ELLIPSE	2.41±1.62	2.50±2.39	2.65±2.54	2.41±1.67
PREDICTED MINOR ELLIPSE RANGE	0.120 – 1.08	0 – 0.811	0.530 – 1.35	0 – 0.671
AVG. DIAMETER ASPECT RATIO (DAR)	1.61±0.64	1.55±1.34	1.54±1.04	1.63±0.54
PREDICTED DAR RANGE	0.952 - 1.66	1.15 – 1.92	1.16 – 1.77	1.10 – 1.75
AVG. CIRCULARITY	0.607±0.23	0.644±0.247	0.650±0.236	0.658±0.375
PREDICTED CIRCULARITY RANGE	0.485 - 0.654	0.486 - 0.6856	0.5391 – 0.6936	0.514 - 0.6887
AVG. AREA CONVEXITY	0.867±0.13	0.906±0.099	0.906±0.122	0.913±0.082
PREDICTED AREA CONVEXITY	0.847 - 0.933	0.805 - 0.906	0.861 - 0.944	0.830 - 0.920
	UNCLAS	SIFIED		<u> </u>



AUC – Ammonium Uranyl Carbonate

$$UO_2^{2+} + (NH_4)_2CO_3 + HNO_3 \rightarrow (NH_4)_4UO_2 \cdot zCO_3 \cdot xH_2O + yNH_4NO_3$$

[U] (mg/mL)	CO ₃ /U Ratio	Stir Rate (rpm)	Addn. Rate (mL/min)	Temp (°C)
50	3.5	170	2.5	21
75	4.25	280	5	35
100	5.0	400	7.5	50


- Synthetic method similar to ADU
- Statistical model used to choose 31 materials to get the most diverse data set
- Complete data set contains 29 independent materials and 2 sets of repeated conditions





AUC Characterization - Color












AUC Characterization - pXRD

Relative Intensity

XRD patterns show four distinct uranium phases in the

data set


 25 compounds contain NH₄NO₃








AUC Characterization – TGA/DSC





Compound 3 - AUCH

Compound 4 – AUC; no NH₄NO₃





AUC Characterization – TGA/DSC


Compound	%NH₄NO₃	Color (Hue Value/Chroma)	CO ₃ /U ratio	Type	
1	7.02	5Y 8/8	3.5	Am	
2	6.7	5Y 8/8	5	Am	
3	12.39	5Y 8/8	3.5	AUCH	
4	0	5Y 8/6	5	AUC	
5	17.84	10YR 8/8	4.25	AUCH	
6	8.53	2.5Y 8/8	3.5	Am	
7	26.55	10YR 8/8	3.5	Am	
8	28.56	10YR 8/8	5	AUCH	
9	11.02	5Y 8/8	4.25	AUC	
10	10.19	10YR 8/8	3.5	AUCH	
11	27.82	10YR 8/8	5	Am	
12	7.46	5Y 8/8	4.25	AUC/ AUCH	
13	22.46	10YR 8/8	3.5	AUCH	
14	13.76	2.5Y 8/8	5	AUCH	
15	11.85	2.5Y 8/8	3.5	Am	
16	21.42	10YR 8/8	4.25	Am	
17	20.33	10YR 8/8	4.25	Am	
18	22.51	10YR 8/8	5	Am	
19	24.23	10YR 8/8	5	Am	
20	16.95	10YR 8/8	4.25	Am	3SIFIE









AUC Characterization - SEM







Compound 3 – AUCH 12.39% NH₄NO₃

Compound 4 – AUC 0% NH₄NO₃


Compound 6 – Amorphous 8.53% NH₄NO₃

Compound 24 – AUO TBD





AUC Characterization - MAMA



Compound 13 – AUCH with 22.46% NH₄NO₃





ADU and AUC Conclusions

- ADU and AUC are precursors to UO₂ fuel and could be interdicted
- Correlations between synthetic conditions and physical, chemical, and morphological characteristics could help identify provenance of stolen material
- It appears that there is no straightforward correlation, however several reaction conditions together seem to lead to changes
 - Morphology, NH₄NO₃ concentration, color
- Statistical models can help us predict measured attributes from MAMA based on combinations of reaction conditions
 - Model has limitations and potential bias






Part 2 – Post-detonation Forensics





Post-detonation Forensics

- Major component of post-detonation analysis is looking at fission yields
- Yields, particularly for higher mass numbers, can help identify the type of device



UNCLASSIFIED

Prelas, M. A.; Weaver, C. L.; Watermann, M. L.; Lukosi, E. D.; Schott, R. J.; Wisniewski, D. A. *Progress in Nuclear Energy* **2014**, *75*, 117.



Goal

- Goal: To create actinide target materials for the rapid separation of fission products without the need to dissolve the entire target
 - Proof-of-principle to advance the library of fission product ratios for various actinides
- Procedure: To prepare and irradiate a target material, then rapidly separate and measure the fission products





UO₂ Fuel

- UO₂ has been used in fuel, target materials, and fission product analysis for decades
 - Literature references site these particle sizes between 20 µm and 200 mm
- Dissolution of materials is generally done in HNO₃ and/or HCl at acid concentrations > 1M






UO₂ Production – A Novel Method

Hydrothermal synthesis


$$UO_2(NO_3)_2 + 3 \xrightarrow[NH_2]{0} \xrightarrow{180 \text{ °C}} UO_2$$



Blakemore, P.; Oregon State University: Corvallis, Oregon, 2017; Vol. 2017, p image of parr



UO_2




Dorhout et.al JRNC, 2019, 319, 1291.





UO₂ Target Production

- KBr chosen as a secondary matrix to trap fission products (3:1 KBr:UO₂ by mass)
- Targets were 25 mg dUO₂
- Pressed into a 6 mm pellet
- Sealed in Al sample holder




Dorhout et.al JRNC, 2019, 319, 1291.



UO₂ Irradiation

 Flattop is a critical assembly device made of HEU at the Nevada National Security Site






Brewer, R. W.; McLaughlin, T. P.; Dean, V. *Uranium-235 Sphere Reflected by Normal Uranium Using Flattop*, Nuclear Energy Agency, 1999.





Rapid Separation








Rapid Separation













Gamma Counting

- HPGe and BEGe detectors used in experiments
- Each sample (plus a background) was counted for the same amount of time
- Down-side: only gamma emitting isotopes are identifiable











Results – Flattop


- Irradiations done on multiple samples
- Five UO₂ samples studied
 - Four samples of 3KBr:UO₂
 - Each contacted with a different acid
 - 0.01 M HCI, 0.1 M HCI, 0.01 M HNO₃, or 0.1 M HNO₃
 - One sample with no KBr present
 - How important is secondary matrix?
 - Contacted with 0.01 M HNO₃





Results

Percent Extraction of Certain Fission Products



Each target able to allow for extraction of a wide •
 variety of fission products

Black bars represent no KBr – secondary matrix does have an affect

• 0.1 M HNO₃ data is artificially high





Issues

- KBr is easy to work with and remove with dilute acid, but it is activated in the neutron flux to give 82Br
 - Many gamma energies
 - Short half-life, high activity
 - Could be resolved by using a different secondary matrix
- Targets were irradiated at different times under different conditions
 - Cannot compare activities extracted
 - Must compare percent extraction





Conclusions

- Proof-of-concept shown
- 0.01 M HNO₃ chosen as extractant for all future experiments
- Secondary matrix does seem to have a positive affect on extraction
- Different secondary matrix could make analysis easier





mos

Acknowledgements

- LANL
 - Gregory Wagner
 - Dr. Marianne Wilkerson
 - Tyler Mullen
 - Hannah Mullen
 - Julie Gravelle
 - Dr. Christine Anderson-Cook
 - Dr. Kari Sentz
 - Dr. Amy Ross
 - Dr. Brian Scott
- Funding
 - NTNFC Graduate Fellowship
 - Glenn T. Seaborg GRA Fellowship
 - DHS Postdoctoral Funding

UNLV

- Dr. Ken Czerwinski
- Dr. Thomas Hartmann
- Julie Bertoia
- Trevor Low
- Dr. Daniel Mast
- Dr. Daniel Lowe
- Rebecca Springs
- Dr. Lucas Boron-Brenner
- Radiation Safety Staff
- DAF
 - Dr. Todd Bredeweg
 - Dr. Donnette Lewis
 - Radiation and Safety Staff

This material is based upon work supported by the U.S. Department of Homeland Security under Grant Award Numbers 2012-DN-130-NF0001-02 and HSHQDC-15-X-B0003.

The views and conclusions contained in this document are those of the authors and should not be interpreted as necessarily representing the official policies, either expressed or implied, of the U.S. Department of Homeland Security.

