

LA-UR-20-21743

Approved for public release; distribution is unlimited.

Title: Impedance/Dielectric Spectroscopy and Theory/Engineering Implications

Author(s): Findikoglu, Alp Tugrul
Yoon, Tae-Jun
Vigil, Matthew Joseph
Sharan, Prashant

Intended for: LDRD review

Issued: 2020-02-21

Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by Triad National Security, LLC for the National Nuclear Security Administration of U.S. Department of Energy under contract 89233218CNA000001. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

Impedance/Dielectric Spectroscopy and Theory/Engineering Implications

Alp T. Findikoglu, Tae Jun Yoon, Matthew J. Vigil, and Prashant Sharan




LDRD Project 20190057DR
PI: Robert Currier (C-PCS)
Co-PI: Artaches Migdissov (EES-14)
February 24, 2020



Managed by Triad National Security, LLC for the U.S. Department of Energy's NNSA


Motivation

- ❑ Impedance Spectroscopy (**IS**), Dielectric Spectroscopy (**DS**), and Cyclic Voltammetry (**CV**)
 - 1) to understand **ion structure and properties** in water in **large P/T-phase space**
 - 2) for **in situ diagnostics and monitoring** in **batch and flow processes**
 - 3) (with **electrodes**) to apply **external drive forces** for **selective ion removal**




Introduction - I

- Impedance Spectroscopy (**IS**), dielectric spectroscopy (**DS**), and Cyclic Voltammetry (**CV**) method description




Introduction - II

- ❑ To understand ion structure and properties in aqueous solutions:
 - combine **spectroscopic** and **electrochemical methods** with **modeling**




Introduction - III

- ❑ Use spectroscopic and electrochemical methods for **in situ diagnostics** and **monitoring** in **batch** and **flow processes**




Batch System



- 5000 psi, 500 °C
- In situ sampling
- In situ IS and DS



Flow System



- 5000 psi, 550 °C
- Two solution mixing
- In flow sampling
- In situ IS and DS

Introduction - IV

□ Application of **external drive forces** for **selective ion removal**:

- Faradaic (e.g., redox absorption) and Non-Faradaic (e.g., electrostatic adsorption) effects
- Large-area and/or functionalized electrodes or transfer media
- External drive induced/controlled adsorption, absorption, or permeation
- External drive induced/controlled precipitation enhancement/inhibition

Possible paths:

- **Electric field effects on ion transport** (e.g., electric field across membrane)
- **Electrostatic ion removal** (e.g., CDI, MCDI)
- **Electric field driven nucleation/growth** (e.g., Electrostatic precipitator for salts)






Figure 11-4b Molecular Biology of the Cell 6e (© Garland Science 2015)

Porous Carbon Electrode (-)



Porous Carbon Electrode (+)





R&D Approach & Current Status

Experimental Conditions	IS		DS		CV		Ext. Force	
	EXP.	SIM.	EXP.	SIM.	EXP.	SIM.	EXP.	SIM.
Ambient Conditions	✓	✓	✓	✓	✓	✓	✓	✓
Elevated P and T	✓	✓	✓	✓	✓	✓	✓	✓
Near/supercritical	✓	✓	✓	✓			✓	✓
Batch System	✓	✓	✓	✓			✓	✓
Flow System	✓	✓	✓	✓			✓	✓

- ☐ Build experimental capability (✓), test in ambient conditions; cross-validate with theoretical predictions and MC/MD simulation results (✓). In progress (✓)
- ☐ Develop high temperature/pressure in situ electrodes that are corrosion resistant; cross-validate with theory/simulations
- ☐ Implement in batch and flow systems for diagnostics/monitoring
- ☐ Search for external field effects for enhanced or ion-selective desalination

Project Outcomes - I


❑ Specific conductance measurement of NdCl_3 (aq) at elevated temperature and pressure



- ❑ Implemented IS capability and numerical algorithms to extract the conductance
- ❑ Specific conductance shows a maximum as Yoon showed in the MD simulations
- ❑ Different ion pairing behavior observed in NdCl_3 vs NaCl solutions at the same concentration

Project Outcomes - II


□ DS of NdCl_3 in water and methanol



Dielectric spectrum measurement results and its decomposition based on relaxation time distribution

Principles behind the reflection measurement technique

- Challenging to implement DS in high-pressure/high-temperature cell
- Demonstrated the suitability of the method to study ion cluster/complexation behavior
- Implemented capability and algorithms for DS measurement of variety of liquids



Project Outcomes - III

❑ Publications

Experiment/Modeling:

“Electrical conductivity, ion pairing, and ion self-diffusion in aqueous NaCl solutions at elevated temperatures and pressures,”

Yoon, T. J., Patel, L. A., Vigil, M. J., Maerzke, K. A., Findikoglu, A. T., & Currier, R. P. (2019)., J. Chem. Phys., 151(22), 224504.

Dielectric Spectroscopy (DS):

“Dielectric relaxation of neodymium chloride in water and in methanol,”

Yoon, T. J., Vigil, M. J., Raby, E. Y., Singh, R. P., Maerzke, K. A., Currier, R. P. & Findikoglu, A. T. (2020), J. Mol. Liq. (under revision)

Impedance Spectroscopy (IS):

“Specific conductance of NdCl_3 in water along the vapor-liquid equilibrium,”

Yoon, T. J., Vigil, M. J., Sharan, P., Singh, R. P., Maerzke, K. A., Currier, R. P. & Findikoglu, A. T. (2020), J. Chem. Eng. Data (in preparation)

Summary of Outcomes and Future Work

- ❑ Built experimental capabilities (IS, DS, CV) and tested them in ambient conditions, and cross-validated them with theoretical predictions and results of MC/MD simulations
- ❑ Developed high-temperature/high-pressure in situ electrodes/probes that are corrosion resistant, and are in the process of deploying them in our batch and flow reactors
- ❑ Demonstrated the ability to use external drive forces (qE) to remove ions from simple salt solutions both experimentally and numerically
- ❑ Future work will include spectroscopic and MD/MC studies of multi-salt systems, implementations in batch and flow reactors, and investigations of the use of external drive forces for enhanced/selective separation of ions from complex salt solutions