

LA-UR-20-24894

Approved for public release; distribution is unlimited.

Title: Measuring the Properties of Actinide-Molten Salts

Author(s): Monreal, Marisa Jennifer
Jackson, Jay Matthew

Intended for: Invited Seminar

Issued: 2020-07-06

Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by Triad National Security, LLC for the National Nuclear Security Administration of U.S. Department of Energy under contract 89233218CNA000001. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

Measuring the Properties of Actinide-Molten Salts

LLNL Chemistry of Nuclear Materials Group
Seminar Series

Marisa Monreal

Inorganic, Isotope, and Actinide Chemistry (C-IIAC)

mmonreal@lanl.gov

J. Matt Jackson

Nuclear Materials Science (MST-16)

jayjacks@lanl.gov

Los Alamos National Laboratory

June 4, 2020



In this photograph of a Los Alamos experiment, a mirror is positioned to view molten salt inside a furnace.

Aircraft Reactor Experiment (ARE) and Molten Salt Reactor Experiment (MSRE)



ARE building at ORNL that was retrofitted to house the MSRE.



The NB-36 flew multiple flights in the 1950s carrying an operating MSR; crew worked from a lead-shielded cockpit (12 tons!).



MSRE graphite core



ARE reactor core: BeO moderator blocks and circulating fuel tubes.

- Aircraft Reactor Experiment (“ARE”), 1954, ORNL
 - ARE = 1st reactor to use circulating molten salt fuel
 - For propulsion of supersonic aircraft (!)
- Molten Salt Reactor Experiment (MSRE) @ Oak Ridge National Laboratory (ORNL) was constructed by 1964, went critical in 1965, operated until 1969 (*equivalent to ~1.5 years of full power operation*)
- The MSRE graphite core also moderated it
- **MSRE fuel: $\text{LiF-BeF}_2\text{-ZrF}_4\text{-UF}_4$** (65-29-5-1; first uranium-235, later uranium-233)
- Its secondary coolant was “FLiBe” (2 LiF-BeF_2)
- Operation temperature: 650°C

Molten Salt Reactor Fuel: Actinide-Molten Salts


Actinide-molten salt fuel:

Actinide halide(s) dissolved in alkali or alkaline earth metal halide(s) at 450 – 850 °C

Examples:

- fluoride system: UF_4 dissolved in $LiF-BeF_2-ZrF_4$
- chloride system: UCl_3 dissolved in $NaCl$


- **Why liquid fuel/coolant?**
 - Damage-resistant (release, rather than trap, fission product gases, avoiding damage from high pressures; quick healing)
 - High operating temperature (increased plant efficiency)
- **Why molten salt?**
 - Stable at low pressures
 - Low viscosity
 - Good heat transfer properties
 - Good solubility of actinide halide and fission products
 - Conductive
 - Refueling without enrichment
 - Can re-use and consume spent fuel from other reactors
 - Enhanced safety
 - More complete burnup




Graphic from US DOE-NE

Growing Number of MSR Developers...and Fuel Salts


Reactor	Fuel Salt
Integral Molten Salt Reactor Terrestrial Energy, Inc., Canada thermal	Low enriched U-, Pu-, Th-, fluoride or any mixture of these
Compact Molten Salt Reactor Seaborg Technologies, Denmark thermal, waste burner	Eutectic sodium-actinide fluoride
Copenhagen Atomics Waste Burner Denmark thermal, waste burner	LiF-ThF ₄
ThorCon, Indonesia thermal	NaF-BeF ₂ -ThF ₄ -UF ₄ (76-12-9.5-2.5)
FUJI International Thorium Molten-Salt Forum, Japan	LiF-BeF ₂ -ThF ₄ - ²³³ UF ₄ (71.76-16-12-0.24) mol%
Stable Salt Reactor Moltex, United Kingdom fast spectrum, waste burner	NaCl-PuCl ₃ -UCl ₃ (60-20-20) with lanthanide trichlorides
Stable Salt Reactor Moltex, United Kingdom thermal	50/50 UF ₃ /UF ₄ diluted in NaF-RbF
Liquid Fluoride Thorium Reactor FLiBe Energy, USA thermal, breeder	LiF-BeF ₂ -UF ₄
Molten Chloride Fast Reactor Elysium, TerraPower, both USA fast spectrum, breeder	NaCl-XCl ₂ -UCl _{3/4} -PuCl ₃



Elysium's modular MCSFR



FLiBe's "LiFTR"



TerraPower's MCFR

LANL Collaborations and the NE-MSR Landscape

Nuclear Energy (NE) - Molten Salt Reactor (MSR) Landscape




MSR Deployment



- LANL collaborations also include universities, other reactor developers
- Other national labs, EFRCs, etc. also in the landscape

TerraPower is working with partners to demonstrate and commercialize MCFR Technology



DOE LAUNCHES \$230 MILLION ADVANCED REACTOR DEMONSTRATION PROGRAM


New program designed to help domestic private industry demonstrate advanced nuclear reactors in the United States.

**Announced
May 14,
2020**

Why Chloride Salts?


Compared to fluoride salts, chlorides:

- ✓ enable harder neutron spectrum which results in enhanced breeding
- ✓ have better solubility properties: lower melt point solutions with larger amounts of actinide chloride
- ✓ have lower viscosities
- ✓ are more thermally stable
- ✓ are safer
- ✓ are more economically viable to produce






Overlapping areas: MSRs and Actinide Metal Purification

Molten chloride salts have been used for decades in **plutonium** and **high enriched uranium (HEU)** purification processes.



In the intersection:

- Preparation and characterization of solvent salts
- Production of actinide halides (e.g. PuCl_3 , UCl_3)
- Study of thermophysical properties
- Study of chemical properties
- Evaluating materials of construction in extreme environments
- Development of in-situ diagnostics
- Mitigating side reactions and investigating impurity chemistry
- Identifying signatures and diversionary tactics



An example MSR (left) and plutonium purification @ LANL (right)

Pyroprocessing of spent fuel @ ANL

With Unique Fuel comes Unique Challenges


Instead of micro-structure evolution, the challenge for MSRs is chemical evolution due to fission and corrosion products and their impact on chemistry, corrosion, phase equilibria, and thermophysical properties

Chemistry: each MSR reactor type, the fuel cycle must be developed and understood with time.

- Noble gases Xe and Kr can be removed
- Most fission products are soluble. What precipitates? What can be filtered?

Corrosion: Fuel evolution impacts the redox chemistry of the system. This needs to be understood and in some cases mitigated (e.g. MSRE added Be to fuel periodically to keep the solution slightly reducing).

Phase Equilibria:




Thermophysical Properties: A robust understanding of composition and temperature dependence needs to be established. Experimental data is lacking (especially for chloride mixtures).

Critical Properties and Our Overall Research Approach

*“Verification of the second law of thermodynamics requires four thermophysical property measurements: **density, thermal conductivity, heat capacity, and viscosity**. You need all four or you don’t need any”*

- Nicholas Smith, Deputy Directory, National Reactor Innovation Center (INRIC)


Property	Application	Experimental Techniques
Density (ρ)	Thermal Hydraulics, Neutronics	Neutron Radiography; Conventional Dilatometry
Heat Capacity (C_p)	Heat and Energy Transfer	DSC
Viscosity (μ , ν)	Thermal Hydraulics	Dynamic Neutron Radiography; Viscometry
Phase Stability, Solubility	Operating Parameters, Salt Composition	DSC, Drop Calorimetry, ERNI
Thermal Diffusivity (α)	Heat and Energy Transfer	Laser Flash Analysis



Neutron Imaging Capability at LANSCE

Neutron counting detector

- Positioned at 8.2 m from the neutron source
- $28 \times 28 \text{ mm}^2$ active area
- Position and time of arrival for each detected neutron





Flat Amorphous Si Panel Specs:

Company/Model:	Varian 2520DX
Active Material:	Amorphous Silicon
Conversion Material:	Gd ₂ O ₃ S
Active Area:	19.5 x 24.4 cm
Pixel Matrix:	1,536 x 1,920
Pixel Pitch:	127 μm^2
Frame Rate:	30 fps (half res)

Neutron Beam at FP5:

Neutron Energies:	Thermal - Epithermal
Rep-rate:	20 Hz
D Collimation:	2 cm



Neutron radiography affords the ability to probe large volumes, and observe interaction with both light and heavy elements

Energy Resolved Neutron Imaging (ERNI)

Neutron Radiography with Falling Sphere Technique: Viscosity (η , ν), Density (ρ)



Falling Sphere Viscometry

- **Determine viscosity:**
 - Measure the elapsed time required for sphere to fall under gravity through a sample-filled tube
 - Use spheres of two different materials to **derive density** (Stokes' Law)

$$\eta = \frac{2gr^2(\rho_{\text{sphere}} - \rho_{\text{melt}})}{9v}$$



Neutron Radiography

- Dynamic neutron radiography can be used to precisely observe and record spheres falling through molten salt



J. Non-Newtonian Fluid Mech. **112** (2003) 203–215

Test Apparatus Installed at LANSCE: ER-2 Flight Path 5



Beam's perspective


Prototype: Version 1

- Capable of measurements up to 1150 °C
- Active water cooling/cold trap
- Inert gas (argon) environment
- Modular construction




From door of flight path


Neutron Beam and Detector Simulations



Simulation of test apparatus in Flight Path 5 at LANSCE, showing neutron beam, collimation, furnace





MCNP Simulation:
borosilicate sphere
within **Fluorinert**
standard, quartz
tube, in neutron
beam



Fluorinert (FC-70)

Fluorinert (FC-70) was used as the calibrating fluid.

Static Fluorinert Radiography: Evaluating Sphere Materials



Fluorinert FC-70: Dynamic Viscosity (η) at Room Temperature

From the velocity of the sphere, the viscosity was calculated as follows:

$$\eta = \frac{2 \cdot g \cdot r_{\text{sphere}}^2 (\rho_{\text{sphere}} - \rho_{\text{liquid}})}{9 \cdot v_{\text{sphere}}}$$

$$\rho_{\text{liquid}} = 1.9259 \text{ g/cc}$$

$$\rho_{\text{borosilicate}} = 2.23 \text{ g/cc}$$

$$r_{\text{sphere}} = 1 \text{ mm}$$

$$g = 9.80665 \text{ m/s}^2$$


Temperature: 30 °C

Known viscosity: 0.0173 Pas

Estimated Velocity: 38.98 mm/sec
(25 °C)

Measured Velocity: 33.8 mm/sec

Measured Viscosity: 0.0196 Pas



Rate: 5 frames per second

Viscosity: $\text{NaCl} + 16.5\text{wt}\%\text{UCl}_3$

- Inert Atmosphere (flowing)
- Temp: 825 °C

$$\eta = \frac{2 \cdot g \cdot r_{\text{sphere}}^2 (\rho_{\text{sphere}} - \rho_{\text{liquid}})}{9 \cdot v_{\text{sphere}}}$$


$$\rho_{\text{liquid}} = 2.0355 \text{ g/cc}$$

$$\rho_{\text{borosilicate}} = 2.23 \text{ g/cc}$$

$$r_{\text{sphere}} = 1 \text{ mm}$$

$$g = 9.80665 \text{ m/s}^2$$

- Measured Velocity: 1.38 cm/sec ± 0.02 cm/sec
- Measured Viscosity: 0.030 Pas*
- **There is no published data to compare to!**
- Predictions/estimates were incorrect




2 frames per sec

Average Measured Velocity: 1.38 cm/sec ± 0.02 cm/sec



*required our density measurement

Setup for Neutron Dilatometry Measurements



Measurements were performed
Fall 2019

Neutron Beam at FP5:

Neutron Energies: Cold - Epithermal
Rep-rate: 20 Hz
Beam Area: $\sim 9 \text{ cm}^2$ (on camera)

New High-Resolution Neutron Imaging Camera

Scintillation Plate:

Company/Model: RC-TriTEC
Conversion Material: $\text{Gd}_2\text{O}_2\text{S:Tb}$
Thickness: $20 \mu\text{m}$
Resolution: $27 \mu\text{m}$



CCD Camera

Company/Model: ATIK 490ex
Pixel Matrix: 3379×2703
Pixel Pitch: $3.69 \mu\text{m}^2$
Cooling: Thermoelectric
Average Exposure: 1 to 30 mins


Density as a Function of Temperature: Fluorinert (FC-70)

- Density a different way: A well-characterized stainless steel capillary tube is used to contain the fluid; volume of a sample of known mass measured at different temperatures

Compared with reference values, our measured density values are lower by only 0.05%
(*Extrapolated error: < 0.18%*)




Meniscus




Scale and distances are measured with ImageJ

Neutron Dilatometry Measurements of Molten Salts

LiCl+KCl (A) and LiCl+KCl+ 5wt%UCl₃ (B)





NaCl+ 90wt%UCl₃ (A) and NaCl+ 80wt%UCl₃ (B)




ImageJ Analysis of Neutron Dilatometry Measurements

Mapping out the shape of the meniscus at each temperature
(allows for more accurate determination of molten material volumes)




Meniscus growth as a function of temperature in UCl₃(16 wt%) + NaCl




This technique can be expanded to include uncertainty analysis!

Summary of Molten Chloride Neutron Dilatometry Experiments



Integrating Modeling with Empirical Density Results


- Top and bottom sets of data: pure UCl_3 and NaCl
 - Modeling data close to experimental data
- Center set of data: 28 mol% UCl_3 in NaCl
 - Experimental data (blue dots) *lower* than simple average density based on mass fraction (gray trace)
 - Modeling data not as close for mixture as for pure systems; required incorporation of Van der Waals interactions and magnetism
 - These observations are prompting the next stages of our research!



Conventional Dilatometry


Netzsch 402C
LVDT

-160-500 °C
RT-1600 °C
Single sample



Push-rod dilatometer;
Used on Pu metal samples


- Complements neutron dilatometry – higher throughput
- Plutonium instrument available
- Preliminary testing underway




First sample holder tests: varied salt type, pellet size, temperature, materials of construction

Differential Scanning Calorimetry (DSC)

- Determine liquidus/solidus transition temperatures (**melt point**, T_m)
- Assess thermal stability based on endothermic/exothermic events
- Plutonium instrument available
- **Our current status:**
 - Calibrated for high temperature (400-1100 °C) measurements on molten chloride salts
 - Uranium-molten salt melt points collected; next step is to take heat capacity measurements (standards made)




Netzsch DSC 404 F1 Pegasus
Max temp: 1650 °C



NaCl + 70 wt% UCl₃ ($T_m = 517\text{ }^{\circ}\text{C}$)


$$C_{ps} = C_{pst} \frac{\Delta q_s}{\Delta q_{si}}$$





Contour map of the experimental data measured for the NaCl- UCl_3 - CeCl_3 system.

Using Melt Point to Determine Sample Purity

- With this new capability for measuring actinide molten salts, can determine **sample purity** of molten actinide salts (here, an old sample of UCl_3 from Y-12 is found to be impure)
- Will be useful for post-radiography experiments






Planning & Preparation Stage: Laser Flash Analysis (LFA) and Drop Calorimetry



- The **laser flash analysis (LFA)** technique is currently the most widely accepted method for precise measurement of thermal diffusivity
- LFA has been adapted for the study of liquid metals, but to date there is no published LFA data on actinide-molten salts
- Current work: sample holder design
 - Must address radial heat loss due to convection
 - Plan is to increase one-dimensional heat flow, while remaining sealed against pressurization and high temperature
- Schematic of high-temperature twin Calvet-type calorimeter—unique to LANL (EES Division, Hongwu Xu)
 - *Enlarged region:* assembly for **drop solution calorimetry** in molten solvent
- Provides heat of dissolution, and enthalpies of mixing
- Demonstrated on plutonium samples; goal is to adapt for molten salt

Chemical Properties

- **Local Structure Experiments (Planned)**
 - Neutron Pair Distribution Function Analysis
 - Raman Spectroscopy
- **Speciation and Impurity Chemistry (Ongoing)**
 - Cyclic Voltammetry
 - Square Wave Voltammetry
- **Corrosion and Materials Evaluation**
 - Cyclic Potentiodynamic Polarization
 - Static and pseudo-dynamic exposure



Project Team

Modeling and Simulation

David Andersson (MST-8)

Differential Scanning Calorimetry

Scott Parker (C-IIAC)

Meghan Gibbs (MST-16)

Doinita Neiner (MST-16)

Josh White (MST-8)

Conventional Dilatometry

Jeremy Mitchell (MST-16)

Najeb Mohammed Abdul-Jabbar (MST-16)

Sendin Bajric (MST-16)

Neutron Radiography

Sven Vogel (MST-8)

Alex Long (MST-8)

Scott Parker (C-IIAC)

Electrochemistry

Kirk Weisbrod (E-2)

David Rodriguez (PT-1)

Charles Lhermitte (C-IIAC)

Research supported by: LDRD #20190622ER and # 20190650DI

This work was performed, in part, at the Los Alamos Neutron Science Center (LANSCE), a NNSA User Facility operated for the U.S. Department of Energy (DOE) by Los Alamos National Laboratory (Contract 89233218CNA000001).

Resources & Contact Info

1663 Article on Monreal-Jackson Molten Salt Research, “Refueling the Reactor”, January 2020
<https://www.lanl.gov/discover/publications/1663/2020-january/refueling-the-reactor.php>

The Nuclear Powered Plane – YouTube Video
<https://www.youtube.com/watch?v=9Jt924xjaJo>

DOE-NE Advanced Nuclear Reactor Articles (with mentions of MSRs):
<https://www.energy.gov/ne/articles/swipe-right-nuclear-6-eligible-advanced-technologies>
<https://www.energy.gov/ne/articles/3-advanced-reactor-systems-watch-2030>
<https://factsheets.inl.gov/FactSheets/molten-salt-reactor.pdf>

Marisa Monreal

Inorganic, Isotope, and Actinide Chemistry (C-IIAC)

mmonreal@lanl.gov

J. Matt Jackson

Nuclear Materials Science (MST-16)

jayjacks@lanl.gov

Los Alamos National Laboratory