

LA-UR-21-21764

Approved for public release; distribution is unlimited.

Montage (stitched 20X images) Pit Assessment of FY16 DE05 Title:

Author(s): Kaufeld, Kimberly Ann

Wendelberger, James G. Kelly, Elizabeth J.

Intended for: Report

Issued: 2021-02-23



Montage (stitched 20X images) Pit Assessment of FY16 DE05



Kimberly Kaufeld Jim Wendelberger Elizabeth Kelly



Montage (Stitched) Analysis for Zone 3 Sections 1-14 (Sub-subsections)


Four Sections: A-D (cut lid in quarters)

8 Subsections: A1 – D2 (cut section in half)


14 Sub-subsections in Zone 3: 1-14 (scanning areas set to reduce curvature)

4 Sub-subsections in Zone 1&2: a-d

One montage image per sub-subsection



Zone 3: 14 sections (sub-subsections)



Zone 1 & 2 : 4 sections (sub-subsections)

Montage (Stitched) Image versus 20X LCM images

- 20X LCM higher resolution than montage (stitched) images
 - -20X LCM pixel is 0.7 microns per side
 - Current montage specification results in pixels with between 2 and 5 microns per side
- Comparison to 20X LCM and Gwyddion analysis show that montage data analysis does a good job of capturing pit depths, area, volume and other statistics of interest


Automated Pit Analysis for FY16DE05 Stitched Images

For FY16 DE05 Sections D1 and D2 lost about 20% of the ICCWR during the weld removal process

D2 (All of Zone 1&2 was lost, dark area in zone 3 is off sample). D2 not used in analysis




D1 (Part of Zone 1&2 and Zone 3 for Sections 9-14 [not used in analysis]



Note that edges (sub-subsections 1 and 14 have considerable area off sample and are not included in the automated analysis [analyzed individually])


Example of an edge image that was removed for automated analysis: B2 Section 1



- Edge sections have black\dark grey areas.
- The black\dark grey areas are not on the sample. It means that the surface in that region is too deep or out of the height scanning range of the LCM.
- On edge sections
 (Section 1 and 14) most deep features are found in the off-sample area.
- These features can be over 100 microns deep and are not representative of the sample.

Height Data Summary- FY16 DE05 Zone 3

White areas are images that are not analyzed by automatic software



Maximum Depth in Microns Below the Surface
Montage FY16_DE05TS20201012162334
OutCutOffsBelow-10Above10/OutCutOffsBelow-10Above10

Total Number of Features: 936
Average Feature Depth:
-24.55 microns
Deepest Feature Depth:
-62.81 microns
Average Feature Eccentricity:
0.778

Height Flagged Features from Selected Images

0 10 20 30 40 50 60 70

Maximum Feature Depth Below the Surface in Microns

Minimum Feature Pixels = 5, Maximum Feature Pixels = 100000

Maximum Feature Euler # = -5, Maximum Feature Eccentricity = 0.95

Pit rankings based upon depth and volume

	Rank	Rank Pit		MaximumDepth			
imagename	Volume	Depth	NumPixels	Microns	onsCubed	CentroidRow	CentroidColumn
FY16_DE05_SW_B2_Zone_3_							
Section_13.vk4	8	1	21	-62.81314	-4930.32461	336.7619	749.1905
FY16_DE05_SW_D1_Zone_3							
_Section_8.vk4	3	2	60	-60.31078673	-53145.05713	1331.316667	1158.71667
FY16_DE05_SW_D1_Zone_3							
_Section_2.vk4	\mid ϵ	3	6	-58.9488149	-11094.17849	314.089744	577.5
FY16_DE05_SW_D1_Zone_3							
_Section_4.vk4	4	4	86	-55.63530687	-13936.37717	341.7093023	1255.74419
FY16_DE05_SW_B2_Zone_3_							
Section_3.vk4	1	. 5	446	-52.64095968	-70534.86766	393.9596413	1309.74215
FY16_DE05_SW_C1_Zone_3_							
Section_2.vk4	5	6	101	-47.74978182	-12077.00169	128.1386139	749.405941
FY16_DE05_SW_B2_Zone_3_							
Section_5.vk4	2	. 7	328	-46.03733633	-54755.16143	360.4054878	1412.14329
FY16_DE05_SW_B1_Zone_3_							
Section_13.vk4	7	' 8	31	-44.62994281	-5707.625063	601.6774194	896.064516

The deepest pits are not necessarily the ones with the greatest volume

In addition to table, software generates many feature statistics, eccentricity, area, number of holes (sponginess), average depth, perimeter.


Flagged features

- The automated software flags features of interest as red, yellow, and green.
 - Red features: Depths 50 microns or more
 - Yellow features: Depths greater than 20 microns and less than 50 microns (note these features are difficult to see on small plots)
 - Green: Depths less than 20 microns.
- Once the features are flagged by depth, they are ranked by volume to look at the largest features.

Pit Depth B2 Section 3 Histogram Height Data Volume Ranking 1; Deepest Pit Ranking: 5


Flattened Height Data

FY16_DE05_SW_B2_Zone_3_Section_3_Y4_X3.vk4 SmoothN Curvature Removed Height Data Smoothing Parameter = 100000000




Flagged Height Features





Maximum Feature Depth Below the Surface in Microns
Minimum Feature Pixels = 5, Maximum Feature Pixels = 100000
Maximum Feature Euler # = -5, Maximum Feature Eccentricity = 0.95


Detail for B2 Section 3, Volume Ranking 1; Deepest Pit Ranking: 5 (Can drill down to 20X Image)




Pit Depth B2 Section 5 Histogram Height Data Volume ranking 2; Deepest Pit Ranking: 7

Flattened Height Data

FY16_DE05_SW_B2_Zone_3_Section_5_Y4_X5.vk4 SmoothN Curvature Removed Height Data



Flagged Height Features





Maximum Feature Depth Below the Surface in Microns
Minimum Feature Pixels = 5, Maximum Feature Pixels = 100000
Maximum Feature Euler # = -5, Maximum Feature Eccentricity = 0.95


Detail for B2 Section 5 Volume ranking 2; Deepest Pit Ranking: 7

Montage is composed of 105 images (15 rows and 7 columns)


FY16_DE05_SW_B2_Zone_3_Section_5_Y4_X5.vk4
Red Green Blue Laser Optical Data








Individual vk4 file analysis of B2 Section 5 (different depths a result of montage smoothing)





1000

Feature


identified

800

pitred=-50, pityellow=-30, pitrednumpixels=100, pityellownumpixels=50,

Individual vk4 file analysis of B2 Section 5 (Feature pixel depth analysis)

	Maximum Depth Microns	Low Volume Microns Cubed	Centroid Row	Centroid Column
3402	-52.776	-35719.7046	549.781893	524.137566



Distribution of the 3402 pixel depths for the highlighted feature of interest.


Ranking of the pixels for the feature of interest. There are 3402 pixels in the feature.

Pixel ranking	Micron Depth
1st	-52.776
5th	-46.649
10th	-44.852
20th	-43.621


15

Pit Depth Distribution: D1 Section 8 Volume Ranking 3; Deepest Pit Ranking: 2

Flattened Height Data




Flagged Height Features



Maximum Feature Depth Below the Surface in Microns
Minimum Feature Pixels = 5, Maximum Feature Pixels = 100000
Maximum Feature Euler # = -5, Maximum Feature Eccentricity = 0.95


Pit Depth Distribution: D1 Section 8 Volume Ranking 3; Deepest Pit Ranking: 2

Flattened Height Data



Feature identified in this location. Offsample so not real.


FY16_DE05_SW_D1_Zone_3_Section_8_Y7_X8.vk4
Red Green Blue Optical Data



Feature is off sample

Pit Feature Density YX Key: Height Data FY16 DE05 Zone 3

Selected Images



Increased numbers of features in sections 2 and 13 likely a result of larger curvature introducing noise.


Additional Pit Analysis

Los Alamos National Laboratory 10/23/20


Pit Depth Distribution: B2 section 13 Deepest Pit Ranking: 1

Flattened Height Data


FY16_DE05_SW_B2_Zone_3_Section_13_Y4_X13.vk4
SmoothN Curvature Removed Height Data
Smoothing Parameter = 1000000000



Flagged Height Features



Flagged features for B2 Section 13




200 400 600


Pit Depth D1 Section 4 Histogram Height Data Deepest Pit Ranking: 4

Flattened Height Data


FY16_DE05_SW_D1_Zone_3_Section_4_Y7_X4.vk4 SmoothN Curvature Removed Height Data Smoothing Parameter = 100000000



Flagged Height Features



Pit Depth D1 Section 4 Histogram Height Data **Deepest Pit Ranking: 4**



Individual image 20x image for D1 Section 4 Y8 X2

There are 60 individual 20x (15 rows and 4 columns) images that make up the montage of D1 Section 4.

600

700

200


400

600

800

1000

Different depths likely a result of montage smoothing / 20X can be a single pixel or raised area near pit. Need to look at individual pixels.



NumPixels

MaximumDepth LowVolumeMicr

-86.1538

onsCubed

-10751.7965

Microns

628

500

1000

CentroidRow


455.699045

CentroidColumn


530.89172

Height Data Summary- FY15 DE07 Zone 3

First container, Michael was experimenting with sectioning



Note that deepest pit (-60.08) in histogram was in C2 Section 1. An edge piece that was not removed. Further analysis showed that this feature was in the off sample portion, so not valid. The actual deepest pit was in B1 Section 8 (-56.7 microns).




Maximum Feature Depth Below the Surface in Microns
Minimum Feature Pixels = 5, Maximum Feature Pixels = 100000
Maximum Feature Euler # = -5, Maximum Feature Eccentricity = 0.9


25

Height Data Summary- FY15 DE08 Zone 3

Just discovered that there is a problem with data from A2, so it is not correct. But based on the remainder of the data it appears that this container has deeper pits than the previous two. Michael reported that this lid had more agglomerated pits than the other containers.



The deepest pit (-82.09) in histogram was in D2 Section 12 (Y8 X12 on montage).



Height Flagged Features from Selected Images

Maximum Feature Depth Below the Surface in Microns
Minimum Feature Pixels = 5, Maximum Feature Pixels = 100000
Maximum Feature Euler # = -5, Maximum Feature Eccentricity = 0.95

26

Los Alamos National Laboratory 10/23/20

Summary

- Montage analysis provides depth and volume of pits for ranking for further investigation by SME
 - Montage max pit depths are generally 10 to 20 microns less than 20X images (montage does more smoothing than 20X)
 - Based on Keyence and Gwyddion analysis, montage depth is a reasonable measure of depth
 - A robust estimator for 20X depth could remove single pixel issues (i.e., use 5th deepest or 10th deepest)
- Based on the montage analysis of first two complete ICCWR DEs, there are no pits deeper than 63 microns in Zone 3. The third container has deeper pits, at least one that is 82 microns deep.
 - Based on pit growth modeling these pit depths support position that a through-wall pit is extremely unlikely over 50 year storage period.
- WAMS resolution comparable to montage (approximately 3.6 micron per side per pixel)
 - WAMS height data likely to be adequate for pit depth / size analysis
- Should we still look at pit depths during surveillance?
 - LANL CWG consensus is that, although we believe that through-wall pitting is not an potential problem for 3013 containers, we don't know enough to stop evaluating pit depths at this time.


Los Alamos National Laboratory 10/23/20

Backup Slides


Los Alamos National Laboratory 10/23/20

Height Data Histogram that includes off-sample regions

The depths are artifacts of the edge of the microscope



Pit Depth Histogram - All Images




Maximum Feature Depth Below the Surface in Microns
Minimum Feature Pixels = 5, Maximum Feature Pixels = 100000
Maximum Feature Euler # = -5, Maximum Feature Eccentricity = 0.95


Pit Depth Distribution: D1 Section 2 Deepest Pit Ranking: 3


Flattened Height Data

FY16_DE05_SW_D1_Zone_3_Section_2_Y7_X2.vk4 SmoothN Curvature Removed Height Data Smoothing Parameter = 1000000000




Flagged Height Features





Maximum Feature Depth Below the Surface in Microns
Minimum Feature Pixels = 5, Maximum Feature Pixels = 100000
Maximum Feature Euler # = -5, Maximum Feature Eccentricity = 0.95


D1 Section 2 Flagged features



Pit Depth C1 Section 2 Histogram Height Data Deepest Pit Ranking: 6


Flattened Height Data

FY16_DE05_SW_C1_Zone_3_Section_2_Y5_X2.vk4 SmoothN Curvature Removed Height Data Smoothing Parameter = 1000000000



The deepest feature is below 50 microns. Anything below 50 would be flagged as a yellow feature.


Flagged Height Features




Pit Depth B1 Section 13 Histogram Height Data Deepest Pit Ranking: 8


Flattened Height Data

FY16_DE05_SW_B1_Zone_3_Section_13_Y3_X13.vk4 SmoothN Curvature Removed Height Data Smoothing Parameter = 1000000000



Flagged Height Features







Maximum Feature Depth Below the Surface in Microns
Minimum Feature Pixels = 5, Maximum Feature Pixels = 100000
Maximum Feature Euler # = -5, Maximum Feature Eccentricity = 0.95

Montage with Deepest Pit (Ranking:1) D2 Section 10 (Piece with an edge or weld region)

Flattened Height Data



Flagged Height Features



D2 Section 10 flagged features

