

LA-UR-21-22645

Approved for public release; distribution is unlimited.

Title: Structured Membrane-electrode Interface for Highly Efficient PEM Fuel Cell

Author(s): Yang, Gaoqiang

Intended for: Interview presentation

Issued: 2021-03-17

Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by Triad National Security, LLC for the National Nuclear Security Administration of U.S. Department of Energy under contract 89233218CNA000001. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.


Structured Membrane-electrode Interface for Highly Efficient PEM Fuel Cell

Gaoqiang Yang


MPA-11, LANL



Conventional Electrode for PEM Fuel Cell




- Random mixture of:
 - Pt on C support (catalyst)
 - Ion-conducting polymer (ionomer)
 - Void space (pore)



Need fast transport of:

- O_2
- H^+
- e^-
- H_2O

- Problem:
 - Thick catalyst layer
 - Long proton/electron transport pathway
 - High mass transport resistance
 - Low mass activity




Cullen, David A., et al. *Journal of Materials Chemistry A* 3.21 (2015): 11660-11667.

Debe, Mark K. *Ecs Transactions* 45.2 (2012): 47-68.

- Whiskers are significantly compressed and deformed, lead to mass transport problem
- Whiskers are compressed into the Nafion membrane, lead to reduction on active reaction sites.
- Limited proton conductive paths in the nano pt-coated whiskers compared to ionomer-containing electrodes.

- **Arrayed membrane with Pillars**


Approach - Ordered Electrode




- Meso-structured electrode relies on vertically-aligned ionomer channels for long-distance H⁺ transport and catalyst support
- Catalyzed elements can have reduced ionomer content

*not to scale

Fabrication Process of Ordered Array Electrode



Fabrication Process of the Ordered Array Electrode




Si template

Pillar collapse during catalyst deposition.


Hot-press with PEM

Dissolving template

Nafion
Arrayed
pillars



Nafion membrane



Pillars collapse

Catalyst deposition

Preventing Nafion pillar collapse

- **Methods:**





- Different forms (H^+ , Na^+ , K^+)
- Templates with different features
- Different coating methods
- Different deposition parameters

- **Pillar length: 10 μm**

- **Spray coating:**

- Ink flow rate: 0.02 ml/min (ultralow)
- Gas flow rate: 0.4 ml/min
- High nozzle-sample distance: 60 cm


Accomplishment #1: Development of a robust method for catalyst deposition with prevention of pillar collapse.




Regular pillar: 15 μm for 0.3 mg/cm^2 loading

- Optimized spraying
- Pillar diameter: 5 μm
- Pillar length: 15 μm
- Relatively good structure with catalyst


15- μm -height pillar




0.15 mg/cm^2 loading




0.27 mg/cm^2 loading




Low loading area at the edge



0.15 mg/cm^2 loading







0.27 mg/cm^2 loading




Arrayed membrane in Fuel Cell Test

- Arrayed membrane provide a better performance compared to flat membrane
- Patterned membrane provide a smaller HFR, due to the reduced Nafion content in catalyst ink and increased proton transport paths in Nafion pillars.




Co-axial Nanowire Electrode


Conventional Electrode*



Array Electrode*



Co-axial Nanowire Electrode*



- CANE relies on vertically-aligned ionomer channels for long-distance H^+ transport and catalyst support
- Electrode with thin Pt film has **reduced ionomer/carbon content**

*not to scale

Fabrication Of Co-Axial Nanowire Electrodes

Anode Aluminum Oxide (AAO) Template





Atomic Layer
Deposition of
Pt Film


AAO Template with Pt




High roughness and high aspect ratio (5-25) utilized




Hot-pressing of
platinized template onto
Nafion membrane






Template Removal
(Acid Etch)





Co-Axial Nanowire Electrodes





- Thicker Pt nanolayer leads to vertical pillars



5um/2.5nm




5um/5nm





5um/7.5nm



Co-Axial Nanowire Electrodes



- Higher mass activity and smaller RO2 explain better performance of 5μm7.5nm
- Conventional CCM: 0.18A/mg_{Pt} and 65 m²/g_{Pt}
- 5μm7.5nm has a lowest RO2



Co-Axial Nanowire Electrodes









Pt loading ($\mu\text{g}/\text{cm}^2$) Current Density (A cm^{-2})

Pt Height thickness	1 μm	2 μm	5 μm
2.5 nm	33.4	50.9	61.3
5 nm	65.7	110.0	188.7
7.5 nm	102.5	150.1	312.4

- Good performance was achieved by CANEs (5 μm 7.5nm)
- However, loading is not the only reason for good performance
 - Similar performance observed from CANEs with different loadings





•Backup

Co-Axial Nanowire Electrodes: Different RHs




- 5 μm 7.5nm provide best performance at 100% RH
- Performance of 5 μm 7.5nm is reduced at high and low RH (150% and 40%)
- CANE electrodes are sensitive to RH

Co-Axial Nanowire Electrodes: Different RHs








- Thicker Pt layer leads to higher HFR at 40% RH, due to the smaller water permeability and higher protonic resistance.








CANE: C-filler

- Sonication procedures: 2min probe + 3h bath
- XC-72 ink with **0.1 I/C**
- Carbon concentration: 0.05%
- Catalysts cover pillars




Cross-shape pillar



- Enhancing the strength of the pillar
- Preventing pillar collap



Cross-shape pillar



23 ug/cm² loading



45 ug/cm² loading



- Different loadings
- No severe collapse is found.
- Catalysts were deposited on the surface

Inverse Array Electrode

Reasoning for inverse pillars:



- Better mechanical strength
- Prevention of pillar collapse

Regular Si template with arrayed holes




Patterned membrane with pillars







Inverse Si template with arrayed pillars




Patterned membrane with inverse pillars




Inverse Array Electrode



Ridge



Si template with ridge



Nafion ridge

- Ridge width: 4.1 μ m/3.7 μ m
- Gap width: 2.0 μ m/2.5 μ m
- Ridge height: 13.4 μ m