

LA-UR-21-22911

Approved for public release; distribution is unlimited.

Title: Non-Radiographic Diagnostics Available at DARHT

Author(s): Pickrell, Mark Manley
Primas, Lori Ellen
Shinas, Michael A.
Kalb, Daniel M.
Schultz, Kimberly Ann
Sullivan, Gregg Kent
Gilbertson, Steve Michael

Intended for: Presentation to Funding Sponsors

Issued: 2021-03-25

Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by Triad National Security, LLC for the National Nuclear Security Administration of U.S. Department of Energy under contract 89233218CNA000001. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

Non-Radiographic Diagnostics Available at DARHT

Mark M. Pickrell, Lori Primas, Steve Gilbertson,
Mike Shinas, Dan Kalb, Kim Schultz, Gregg
Sullivan

March 16, 2021


Summary of Laser / Fiber Optic-Based Diagnostic Types at DARHT

- 128 Channels of Gen IV MPDV
 - Newest version with best signal to noise.
- 128 Channels of Modulation Based Ranging (MBR)
- 52 Channels of Time of Arrival Diagnostic (TOAD)
- 24 Channels of Time Domain Chirped Fiber Bragg Grating (TD-CFBG)
- 4 types, and nominally 16 channels, of fiber optic-based vessel strain measurements
- Fiber-based temperature measurement (in development)
- Additional diagnostics can be brought in as needed:
 - PDV
 - In situ TOAD
 - Capillary TOAD
 - BLR

Excellent complement to radiographic imagery.



Historical Increase in Fiber-Based Diagnostic Channels




Gen IV Multiplexed Photonic Doppler Velocimetry (MPDV)

- Measures implosion velocity.
- Most capable system developed to date.
 - Construction complete by end of FY21
- 128 Channels.
- Significantly improved signal to noise compared to predecessors
 - Based on table-top prototype.
 - Use of time-multiplexed rather than wavelength multiplexed signals \Rightarrow reduced competition for digitizer bits.
- Elimination of the cross talk and Stimulated Brillouin Scattering effects from the Gen III system.
- Available launch power increased from 5 mW to 200 mW per channel.
- Includes feedback stabilization of launch power based on return signal to increase dynamic range from x2 to x200.
 - Will mitigate early loss of data from laser attenuation during the experiment.
- Development, *tabula rasa*, of LANL data analysis code that treats measurement uncertainty properly.



MPDV Gen IV



MPDV – Multiplexed Photo Doppler Velocimetry, ROADDM – reconfigurable optical add-drop delay multiplexer, MBR – Microwave Based Ranging
 XT – Cross timing, OPFS – Optical power feedback stabilization




System Schematic



Existing Racks



Time of Arrival Diagnostic (TOAD)

- Detonation wave arrival time accurate to 200 ps.
- Multiple variants including:
 - Jump Off PDV
 - Capillary TOAD
 - In situ TOAD
- Primary diagnostic for detonator timing measurements.
- Used for both detonator and hydrotest measurements.





Time Domain Chirped Fiber Bragg Grating(TD-CFBG)

- Continuous measurement of detonation wave position and velocity.
- 24 Channels
- Also measures lower-amplitude shock wave spectrum.



Modulation Based Ranging

- Direct measure of implosion surface position.
- Uses existing MPDV optical paths; identical beamlines.
 - Inexpensive: ~\$2k / channel
- Complements MPDV: MPDV \Rightarrow velocity, MBR \Rightarrow Position.
- True 25 μm accuracy over entire measurement range.
- Consistent with MPDV. Upper plot shows MBR agreement with MPDV



Vessel Strain Measurements

- Measures strain response of vessel to impulsive load (i.e. an explosion).
- Used to monitor vessel integrity and predict vessel failure.
- 4 measurements:
 - Local and global **X**
 - Elastic and plastic
- 3 Measurement systems:
 - LUNA Swept Wavelength Reflectometer
 - Real Time Localized Strain (RTLS) Measurements with Fiber Bragg Gratings
 - Spectral Interferometry for Transient Strain (SITS)
- Entirely fiber-optic based
 - Faster response than electrical
 - Highly impervious to electromagnetic interference.
 - Very accurate.

