

## LA-UR-21-24087

Approved for public release; distribution is unlimited.

Title: Destructive and Non-destructive Assay of Special Nuclear Material

Author(s): Koehler, Katrina Elizabeth  
Stinnett, Jacob

Intended for: ETI Consortium lecture series

Issued: 2021-04-28

---

**Disclaimer:**

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by Triad National Security, LLC for the National Nuclear Security Administration of U.S. Department of Energy under contract 89233218CNA000001. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.



# **Destructive and Non-destructive Assay of Special Nuclear Material**

Katrina E. Koehler  
Jacob Stinnett  
*Los Alamos National Laboratory*

4 May 2021


# ETI 101: Fundamentals of Nuclear Science and Engineering for Nonproliferation

## Module 4 - Overview of Nuclear Security and Nonproliferation

*Destructive and Non-destructive Assay Techniques*


by Katrina Koehler and Jacob Stinnett

4 May 2021



# Outline

- Purpose of Destructive and Nondestructive Assay
- Destructive Assay
- Nondestructive Assay by gamma spectroscopy
- Gamma Spectroscopy R&D



# Destructive Analysis



# Destructive Chemical Analysis

NDA and DA methods are used to quantify nuclear material (uranium, plutonium, etc.) for nuclear material accounting, for process control, and more

DA is used to establish the elemental content and isotopic composition of nuclear materials

Examples:

- trace impurity analysis in plutonium oxide
- precise plutonium oxide isotopic analysis

A small portion of the bulk material is substantially changed chemically, physically, or both as a part of the measurement process, typically becoming waste, thus the term “destructive” analysis

# Measurement Process

## 1. Bulk measurement

Volume, Weight, Flow

## 2. Sampling

Random grabs, Core samples

## 3. Sample Preparation

Dissolution, Separation chemistry

## 4. Analytical measurement





# Bulk Measurement of Solids

**Examples:** oxides, scrap materials, product metal

## Problems with recorded weights

- Gain or loss of water
  - Surface oxidation
  - Loss of volatile components
  - Improper technique
  - Poor standards
  - Aging of balance
- } *Unstable, changes in mass over time*
- } Quality Assurance



# Sampling and Sample Preparation

**Collection of a representative sample from bulk material?**

**Prepare sample:**

- Resampling of the collected sample
- Dissolution (acid or fusions)
- Separations (solvent extraction or ion exchange)
- Chemical treatments (oxidation state adjustment, acid strength adjustment)
- Other (e.g., reweighing, shaving)



# Analytical Measurements - Summary of DA Types/Methods

## Gravimetric

- Determination of U

## Alpha Spectrometry/Alpha counting - Pu

## Reduction-Oxidation (Redox) Titrimetry (examples)

- Davies/Gray Titration of U
- Ceric Titration of Pu
- Ferrous Titration of Pu
- Coulometric Determination of Pu

## Spectrophotometry/Fluorometry – U and Pu

## Mass Spectrometry

- Impurity Analysis
- U or Pu isotopic composition
- U or Pu concentration determination by Isotope Dilution Mass Spectrometry (IDMS)



# Multicollector Mass Spectrometry

Method of choice for determination of isotopic composition



Measures isotopes simultaneously

Very good precision and accuracy

- Precision 0.005-0.1% for U/Pu
- Accuracy 0.002-0.06%

Small samples  $10^{-15}$  –  $10^{-5}$  grams

## ★ Mass Spectrometry



A chemist prepares a sample for an IsotopX Phoenix multicollector thermal ionization mass spectrometer (TIMS)



Chemists working with a Neptune Plus multicollector ICP-MS

# Isotope Ratios Measured by Mass Spectrometry

Thermal Ionization Mass Spectrometry (**TIMS**) and Multicollector Inductively Coupled Plasma Mass Spectrometry (**MC-ICP-MS**) applicable to many material types

<sup>241</sup>Pu vs <sup>241</sup>Am

- Isobaric (same mass) interferences must be considered
- Advantages include small sample size and excellent precision
- Disadvantages include complex sample preparation procedures, equipment, and skills



# Non-Destructive Analysis: Gamma Spectroscopy






# Gamma NDA Summary

Isotopes emit gamma-rays with distinct energies

The gamma-rays deposit that specific energy in the detector




# Gamma NDA Summary

When the detector reads a specific energy, we know the corresponding isotope is present

We can tell relatively how much of each isotope is present by the ratio of the counts

- Our item enrichment is 5%  $^{235}\text{U}$  → input into MC&A



For large items, gamma NDA gives the isotopic composition only. Neutron or calorimetry is needed to find the total mass.

Typical measurement time is 10 minutes, typical uncertainty is 1%




# Origin of Gamma-Rays

Gammas are emitted from an excited (energized) nucleus


The nucleus de-excites (loses energy) by emitting one or more gamma-rays

## Gammas from Alpha Decay



# Branching Ratios

Different gammas are emitted with a known probability (“branching ratio”)




U-235 Gammas:	BR
185.7 keV	57%
144 keV	11%
163 keV	5%
205 keV	5%

# The Photoelectric Effect

Gamma-ray fully transfers energy to electron

Gamma-ray is **fully absorbed**

Gamma-ray with energy  $E_1$




Electron with energy  
 $E_2 = E_1$


# Compton Scattering

Gamma-ray transfers some energy to electron


Gamma-ray continues on, **some energy escapes**



# Attenuation of Gamma-rays




**density (g/cm<sup>3</sup>)**  
**mass absorption coefficient (cm<sup>2</sup>/g)**  
**thickness (cm)**



# Features of a Monoenergetic Spectrum


Some energy escapes by Compton scatter, less than the photopeak is recorded




We will mostly focus on full energy peaks

# Energy Resolution

Peaks close in energy require good energy resolution in order to be distinguished from each other



# Uranium Gamma-Ray Spectrum (1-MeV Range)





# Plutonium Gamma-Ray Assay


## Problem statement

Find the mass of Pu in this container, by isotope

- Measure with Gamma to get isotopic %
- Measure with calorimetry or neutron to get power/effective mass
- Combine for mass of each isotope
- Feed into MC&A needs

## 2. Spectrum

## 1. Measurement



# Plutonium Gamma-Ray Assay

## 3. Isotopic ratio analysis with FRAM

- Compares how big each peak is to determine isotopics
- Considers detector efficiency, half-lives, branching ratios, peak shapes, backgrounds, energy calibration, etc.

```
*****
PC FRAM (6.1)      Isotopic Analysis      16-Apr-2020 09:07:34
(Fixed energy Response function Analysis with Multiple efficiencies)
Operator ID:

spectrum source:  C:\FRAMdata\Testspec\TestSpec_chn\93coax8k.chn
spectrum date:    09-Oct-1993 20:39:14
live time:        5714.00 s
true time:        7200.00 s
num channels:     8192
```

```
parameter set:  GeCoax_Pu_120-420 (2019.12.06 14:08)
Pu Coaxial, Equilibrium, U235/Pu < 0.2, 120-420keV
Physical Efficiency, Gain 0.125 keV/ch, Offset 0 keV
comment:
```

```
*****
*****
diagnostics passed.
```

	Pu238	Pu239	Pu240	Pu241	(By Corr) Pu242	%Am241/Pu Am241
mass%	0.01149	93.41436	6.38703	0.15674	0.03037	0.16892
sigma	0.00034	0.05703	0.05712	0.00022	0.00067	0.00170
%RSD	2.96%	0.06%	0.89%	0.14%	2.20%	1.01%

```
$TotPwr 2.59 71.57 17.68 0.82 0.02 7.00
```


```
Specific Power (W/gPu): ( 2.51765 +/- 0.00501)e-003 ( 0.20%)
```

```
Effective Pu240 fraction: ( 6.46701 +/- 0.05714)e-002 ( 0.88%)
```

```
Time since chemical separation: 5582.6 +/- 40.4 days ( 0.72%)
```

	Pu238	Pu239
mass%	0.01149	93.41436
sigma	0.00034	0.05703
%RSD	2.96%	0.06%


# Plutonium Gamma-Ray Spectrum (1 MeV Range)



# Plutonium Gamma-Ray Concerns

Gammas only penetrate outer ~1cm of the Pu, we're only measuring the 'skin'

- Which is why calorimetry/neutron is needed, to measure the whole item
- Example: Gamma assay of 4.5kg Pu BeRP ball only gives a few hundred grams



# Applications for Gamma Spectroscopy

## 1) **Finding** material

- Portal monitors
- Source search

## 2) **Identifying** radionuclides

- Handheld RIIDs
- Manual identification

## 3) **Quantifying** mass/activity

- Holdup measurements
- Waste measurements

## 4. Fundamental **science!**

# Finding Material: Portal Monitors

Able to **quickly** detect radioactive material

Large, high efficiency

Very poor energy resolution




Major focus of NEN-3: International Threat Reduction





## Finding Material: Source search

Since gamma-rays are penetrating and passively emitted, they can be used to search for most radioactive materials.




<https://h3dgamma.com/>

# Identifying Material: Handheld RIIDs

Deployable hardware that

- 1) Collects a spectrum
- 2) Makes an identification

*Usually* low resolution, relatively inefficient








# Identifying Material: Manual Identification

Manual, **human** identification is sometimes needed. Algorithms aren't perfect, and sometimes answers are *alarming*

DOE Radiological Triage provides 24/7 reachback analysis

- Radioactive boxes contain glass.
- GR-135 reports Np-237 & Pu-239.
- Triage identifies Lu-176, no Np, no Pu, no threat.




## Bonus: Isotopic Analysis

Gamma spectroscopy can be used to determine enrichment of uranium or isotopes of plutonium

### NEN-1: Safeguards Science and Technology

Example: Quantities and enrichment of U-235 limited by international treaties



UF<sub>6</sub> enrichment meter



UF<sub>6</sub> cylinder, high resolution measurement

# Quantifying Material: Waste Measurements

## Far-field Gamma Assay:

- Primarily for low-density, homogeneous waste
- Simple analysis

## Problem:

- Not all waste is low-density!
- Not all waste is homogeneous!






# Quantifying Material: Waste Measurements

## Segmented Gamma Scanning


- *Segment* the item into individual layers for the analysis
- Scan along the height of the item while rotating
- Use an external transmission source to account for attenuation




# Quantifying Material: Waste Measurements

## Tomographic Gamma Scanning


- *Segment* the item into voxels
- Scan along two axes of the item while rotating
- Produce 3D “density map” and “transmission map”



*Attenuation*



*Emission*



## Quantifying Material: Holdup


When processing material, some material is left behind in pipes, blenders, gloveboxes, etc.

Must be quantified for MC&A, safety, security



Commercial software:



-ISOCS, ANGLE, ISOTOPIC, SNAP





# Fundamental science

## Gamma Spectroscopy R&D: Microcalorimeters







# Microcalorimeter

*Turn kinetic energy into heat →*

*Measure with a sensitive thermometer →*

*Histogram energy from each event (Spectroscopy!)*

*Superconducting-Normal Transition*






# Microcalorimeter



$$\Delta E \approx \sqrt{4kT^2C}$$

100 mK

Really small sensing elements




## SLEDGEHAMMER



# Microcalorimeter

## Gamma Ray Spectroscopy




Applications in safeguards and material accounting:

Plutonium isotopic composition

- Purified U and Pu products
- U/TRU products
- Fresh MOX fuel
- Wastes


Nuclear data for improved HPGe analysis

- X-ray line widths
- Gamma-ray energies
- Gamma-ray branching fractions



# Microcalorimeter

## Gamma Ray Spectroscopy




*M.P. Croce, arxiv .*

# Microcalorimeter

## Gamma Ray Spectroscopy

PIDIE6



K.E. Koehler, arxiv 2103.15893

Improved nuclear data




Improved HPGe analysis

Energy [keV]	Isotope	NNDC BR	$\mu_{BR}$ [%]	This work BR	$\mu_{BR}$ [%]	$\mu_{BR}$ Agreement
125.21	$^{239}\text{Pu}$	$5.63 \times 10^{-5}$	2.7	$5.51 \times 10^{-5}$	13	-0.2
125.3	$^{241}\text{Am}$	$4.08 \times 10^{-3}$	2.5	$4.08 \times 10^{-3}$	1.0	0.0
144.201	$^{239}\text{Pu}$	$2.83 \times 10^{-4}$	2.1	$2.87 \times 10^{-4}$	1.0	0.6
146.094	$^{239}\text{Pu}$	$1.19 \times 10^{-4}$	2.5	$1.22 \times 10^{-4}$	1.4	0.7
146.55	$^{241}\text{Am}$	$4.61 \times 10^{-4}$	2.6	$4.75 \times 10^{-4}$	0.75	1.2
150.04	$^{241}\text{Am}$	$7.40 \times 10^{-5}$	3.0	$7.76 \times 10^{-5}$	1.3	1.5
152.72	$^{238}\text{Pu}$	$9.29 \times 10^{-4}$	0.75	$9.46 \times 10^{-4}$	0.78	1.7
159.955	$^{241}\text{Pu}$	$6.68 \times 10^{-6}$	1.1	$6.87 \times 10^{-6}$	2.0	1.2
160.19	$^{239}\text{Pu}$	$6.20 \times 10^{-6}$	19	$5.82 \times 10^{-7}$	331	-2.5
161.45	$^{239}\text{Pu}$	$1.23 \times 10^{-4}$	1.6	$1.20 \times 10^{-4}$	1.6	-1.1
161.54	$^{241}\text{Am}$	$1.50 \times 10^{-6}$	20.0	$3.52 \times 10^{-6}$	19.9	2.7
164.61	$^{241}\text{Pu}$	$4.56 \times 10^{-5}$	1.6	$4.46 \times 10^{-5}$	2.0	-0.9
164.69	$^{241}\text{Am}$	$6.67 \times 10^{-5}$	3.7	$7.78 \times 10^{-5}$	4.9	2.4
169.56	$^{241}\text{Am}$	$1.73 \times 10^{-4}$	2.3	$1.72 \times 10^{-4}$	0.9	-0.3
171.393	$^{239}\text{Pu}$	$1.10 \times 10^{-4}$	1.8	$1.12 \times 10^{-4}$	1.4	0.9
175.07	$^{241}\text{Am}$	$1.82 \times 10^{-5}$	5.5	$1.85 \times 10^{-5}$	2.8	0.3
188.23	$^{239}\text{Pu}$	$1.09 \times 10^{-5}$	10	$8.63 \times 10^{-6}$	10.8	-1.6
189.36	$^{239}\text{Pu}$	$8.30 \times 10^{-5}$	1.2	$7.91 \times 10^{-5}$	1.4	-2.6
191.96	$^{241}\text{Am}$	$2.16 \times 10^{-5}$	4.6	$2.01 \times 10^{-5}$	2.8	-1.3
208.005	$^{241}\text{Pu}$	$5.19 \times 10^{-4}$	1.4	$5.34 \times 10^{-4}$	1.9	1.2
208.01	$^{241}\text{Am}$	$7.91 \times 10^{-4}$	2.4	$8.08 \times 10^{-4}$	5.4	0.4

M.D. Yoho, NIM A, 2020.


# A Bright Future for Microcalorimeters

Scalable, high-throughput architecture based on microwave frequency-division multiplexing






# A Bold Future for Microcalorimeters



*Stable readout even with extreme pulse pileup*



# Questions?

Katrina Koehler: [kkoehler@lanl.gov](mailto:kkoehler@lanl.gov)

Jacob Stinnett: [Stinnett@lanl.gov](mailto:Stinnett@lanl.gov)