

LA-UR-21-24510

Approved for public release; distribution is unlimited.

Title: Physical Acoustics Characterization For Inspection and Evaluation

Author(s): Ulrich, Timothy James II
Remillieux, Marcel
Beardslee, Luke Berny
Le Bas, Pierre-Yves

Intended for: Share slides from internal workshop with external colleagues.

Issued: 2021-05-10

Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by Triad National Security, LLC for the National Nuclear Security Administration of U.S. Department of Energy under contract 89233218CNA000001. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

Physical Acoustics Characterization For Inspection and Evaluation

Weapons Focused Additive Manufacturing Workshop

TJ Ulrich (Q-6)

Marcel Remillieux (EES-17)

Luke Beardslee (EES-17)

Pierre-Yves Le Bas (Q-6)

3/24/2021




Physical Acoustics Characterization (PAC)

- The area of acoustics and physics that studies interactions of acoustic waves with gaseous, liquid and/or **solid** media on **macro-** and **micro-**scales ... *to obtain the relevant information about a medium under consideration by measuring the properties of acoustic waves propagating through this medium.* -- Wikipedia
- Properties controlling waves:
 - Material properties (i.e., elastic properties, mass density)
 - Geometry (e.g., exterior shape, internal defects)
 - Boundary conditions
- Uses two main wave modalities:
 - Propagating waves, i.e., transients
 - ***Standing waves, i.e., resonance***


Standing Waves (Resonance)

- A **standing wave**, also known as a **stationary wave** or a **resonance**, is a wave which oscillates in time but whose peak amplitude profile does not move in space.
- Resonance occurs in objects at distinct frequencies, known as resonance frequencies defined by the shape of the object, stiffness of the material, and boundary conditions (e.g., fixed vs. free).
- Standing wave patterns (i.e., vibrational shape) are known as resonant modes.
- Example modes:


Cylindrical Rod



"Dog bone"



Hemispherical shell




Measuring Resonance

- Making resonance measurements requires a **source** of vibration (e.g., controlled transducer, operational noise, etc.) and a vibration **detector** (e.g., piezo-electric accelerometer, laser vibrometer, microphone, etc.)


- Resonance Spectrum (typical):

- excite source transducer at single frequency,
- measure response at single location,
- increment source frequency,
- repeat.



- Resonant Modes:


- Excite at a resonance frequency
- Measure response at multiple locations
 - Typically use scanning laser vibrometer



Resonance Inspection Techniques & Analyses (RITA[®])


Using vibrational resonant response of a structure for:

- ARS: Acoustic Resonance Spectroscopy for signature identification and “finger-printing”
- RUS: Resonant Ultrasound Spectroscopy for measuring material properties (elastic constants, density)
- NRUS: Nonlinear RUS for damage detection & quantification




Portable RITA[®] system (pictured).

ARS



Quick sorting of parts


RUS



Material properties
(moduli, wave speeds, density)

$$C_{ijkl}, \nu_{L,S}, \rho$$

NRUS





Material Integrity Quantification
and Damage Monitoring

Acoustic Resonance Spectroscopy ("Finger Printing")

ARS: Description of the Technology



- Resonances are uniquely determined by geometry, mass density, and elastic tensor.
- Compare resonance spectra to identify changes in the above parameters.
- Use machine learning to automate identification and process large data sets.




ARS Example: Legacy vs. Development Components

- High tolerance on geometry: verified no geometrical differences
- Destructive Testing 1: Hardness; within the error bars, no differences really
- Destructive Testing 2: grain structure; obvious differences that ARS was able to detect

RITA (ARS) nondestructively detected differences







Developmental process resulted in different microstructure



ARS Example: Additively Manufactured Components

- AM dog bone specimens for mechanical testing
- 57 samples analyzed blindly
- 27 samples are self consistent
- Remaining samples indicate considerable variation
- Modal Analysis can be insightful, but not quantitative.



Resonant Ultrasound Spectroscopy (Quantification of Properties)

RUS: Limitations of Traditional Methodology

- Simple geometries (solid spheres, right circular cylinders, rectangular parallelepipeds) required for “forward” calculation of resonance frequencies.
- Free boundary conditions, minimal coupling/impact of source and receiver transducers.
- Rule of thumb: 5 resonance frequencies needed for each independent elastic constant (e.g., 2 constants for isotropic = 10 resonance peaks)
- Must capture lowest resonance frequencies, no missing modes allowed. (exceptions allow a few missing modes, but must know where)
- Inversion process typically requires initial “guess” of elastic constants to be close to actual values.

Material Property Determination of Complex Geometries


Complete Process:

- **Resonance Measurement:** Vibrate component and utilize 3D laser vibrometry to:
 - Measure resonance frequencies
 - Image modal shapes
- **Component Geometry Measurement:**
 - 3D Geometry Scan of Part (Faro Arm, CMM)
 - Post Process 3D Geometry Scan
- **COMSOL Analysis:** FEM using 3D geometry from Faro Arm
 - Compute expected resonance frequencies
 - Visualize expected resonance modes
- **Data Interpretation (Mode Matching):** match resonance frequencies from LV measurements (frequencies and shapes) to results from COMSOL
- **Material Property Determination (RUS Inversion):** using specified frequencies from mode matching, geometry from Faro arm measurements and the COMSOL model, iteratively solve for the properties (***elastic moduli, density, Euler angles***) using a genetic algorithm.


RUS on new PETN Mock: Material Property Determination




3D Laser vibrometer
(receiver)



RITA





Pellet
(with modal response from
3D SLDV overlaid)



RUS Example: Complex Geometry, AM Dog Bones



- AM dog bone specimens for mechanical testing
- 57 samples analyzed blindly
- 27 samples are self consistent
- Remaining samples indicate considerable variation

Origin of the differences?



RUS Example: Complex Geometry, AM Dog Bones


- Utilize FEM based RUS methodology with resonance mode matching.
- Results:
 - All parts have essentially the same Young's Modulus.
 - Self consistent parts have typical Poisson's ratio of >0.33 .
 - Inconsistent parts have varying Poisson's ratios < 0.33
 - Mass density fluctuations $< 1\%$



Nonlinear Resonant Ultrasound Spectroscopy (Defect Detection and Quantification)

Nonlinear Resonant Ultrasound Spectroscopy (NRUS)


- Quantify hysteretic nonlinear elastic parameter (α) from the natural resonances (f , Δf) of an object driven at multiple strain (ϵ) amplitudes.



$$\frac{\Delta f}{f} = \alpha \epsilon$$


Resonance Inspection Techniques & Analyses (RITA) system previously developed for testing of weapons components.

Portable **RITA**® system (pictured).





NRUS: Benefits for Damage Detection

- It has been demonstrated that nonlinear acoustics (including NRUS) is much more sensitive to the presence of damage than linear acoustic techniques.



Normalized evolution of wave-speed (red), linear attenuation (blue) and nonlinearity (black) of a plastic sample subjected to fatigue loading.






- In fact, nonlinear indicators correlate directly with damage density.



Evolution and quantification of damage in a composite plate

NRUS Example: fatigue damage in Haynes 230 Superalloy


Nondestructive Evaluation of Loading and Fatigue Effects in Haynes® 230® Alloy
TA Saleh - 2006



NRUS Example: AM of ABS plastic components


- Tested 4 AM samples(square columns 10mm X 10mm X 30mm).
- Samples were instrumented with piezoelectric transducers.
- The vibrational response of the longitudinal modes of the samples was measured on the side opposite to the transducer using a LASER vibrometer.

Experimental Setup



Laser
Vibrometer


Blind test accurately revealed 1 of the 4 samples to be defective from the quantification of α .



Nonlinear elastic material analysis - meso-scale mechanics

Experimental (NRUS) vs Numerical (HOSS)

- A cross section of granular material was obtained and its grain structure was incorporated into HOSS



- The simulations established a direct link between nonlinear elastic behavior and force chains inside the sample.
- Without the force chains (i.e., without porosity) the non-linear elastic behavior **is not** observed.

Current Activities & Path Forward



Current Projects

- LDRD

- ER Reserve: apply acoustic monitoring (including resonance techniques) to SMR components

- use embedded sensing (fiber Bragg)
- use ambient noise


*AM
stainless
steel*




- DI (through Seaborg Institute): Enhance RUS for Composite Samples

- multiple materials (e.g. bonded samples of more than one material)
- in situ boundary conditions (e.g., fixed vs. free)

*Ta, W, Ta
sandwich*



HE in Al cup



Questions?

