

LA-UR-21-32055

Approved for public release; distribution is unlimited.

Title: ASTM D03 Workshop: Developing a Hydrogen Contamination Detector Analyzer

Author(s): Rockward, Tommy
Brosha, Eric Lanich
Maurya, Sandipkumar
Mukundan, Rangachary
Wilson, Mahlon Scott


Intended for: Workshop: ASTM

Issued: 2021-12-09

Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by Triad National Security, LLC for the National Nuclear Security Administration of U.S. Department of Energy under contract 89233218CNA000001. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

ASTM D03 Workshop: Developing a Hydrogen Contamination Detector Analyzer



Team(alphabetically):

E. Brosha, S. Maurya, R. Mukundan, T. Rockward C. Romero, and M. Wilson

Dec 8, 2021

"This presentation does not contain any proprietary, confidential, or otherwise restricted information"

UNCLASSIFIED

HCD Background

Problem:

Non-hydrogen constituents in the fuel steam can cause irreversible damage to FC systems and therefore should be avoided.

Objectives:

1. Develop a low-cost fast response device (analyzer) to measure impurities in a dry hydrogen fuel stream at or above the SAE J2719 levels.

Analyzer Targets:


SAE J2719 Limit	Filling Time
200 ppb CO	~ 5 min

2. Develop understanding of working mechanism and improve analyzer by **identifying the best materials and their configuration (Timeline of improvements)**
3. Test the analyzer in real-world environments

UNCLASSIFIED

Approach

- Use a **mini fuel cell** in/at the hydrogen stream to detect impurities that can be harmful to the fuel cell stack
- **No oxygen or water** available at the filling station, challenges:
 1. Provide hydration via a **Wicking Scheme (Offline Analysis)**
 2. Operate w/o H₂O inside fuel stream at High P & low T (**Inline Analysis**)
- HCD operates as an electrochemical H₂ pump using a MEA-type configuration. Measure pumping current before, during and after contaminant exposure. (**No Oxygen required.**)



UNCLASSIFIED

Identifying & Testing Desirable Materials (FY15)



Proof-of-Concept Shown

Reference Electrode: Tolerant and Stable

- **Pt: 30 wt %, Ru: 23.3 wt %**, High surface area to mass ratio 3.5nm particle size
- Carbon black with 5% Nafion® painted decals

Working Electrode: Durable and Sensitive

Sputtered low loaded electrode provides stable Pt particle sizes and high sensitivity to impurities.



Desired response times obtained for both CO and H₂S at the SAE level!

Response time < 5 minutes!!!


UNCLASSIFIED

Developing the Prototype(FY16)

- **Membrane Hydration Challenging:** Identifying conditions needed for constant membrane humidification
 - Confirm by measuring HFR w/varying flow and membrane thickness
- Determine a **fuel flow-rate** that will not compromise sensitivity or response time


Membrane Saturated

N212 membrane HFR at 50kHz - 1L/min N2
HFR_Membranehumidification8




N212, HFR increases in the presence dry gas flow

N117 membrane HFR at 50kHz - 1L/min N2
HFR_Membranehumidification8




N117 maintains hydration longer

UNCLASSIFIED





Re-designed hydration scheme

N117 with GDLs
400 ml/min 6%H₂/Ar bal ran overnight continuous
5 hr stability HFR next day
50kHz, HFR_Membranehumidifi_13



Prototype Developed (FY16)




- Newly designed prototype developed using standard FC hardware
- IP protection initiated for membrane hydration system


UNCLASSIFIED

Improved Humidification (FY17)

0.039 mg Pt/cm²; Low Pt, 0.2 mg Pt/Ru (RE) T: 30°C, P: 0 psig,
Flowrate: 100 sccm



- Baseline experiments
- Gases were externally humidified
- 25 BC GDL
- CO exposure shows clear response



- Dry gases with **wicking humidification system**
- GDL changed to a less hydrophobic material
- More stable than 'Baseline'
- Responds to 200 and 500 ppb CO

No natural recovery observed !!!

UNCLASSIFIED

Applying a Clean-Up Strategy (FY17)


How to reset the analyzer?

- Applied 0.75V as a 'Clean-Up' Method
- Analyzer reset after 200 ppb CO
- **Recovery not complete at highest concentrations**

Imp Spectras for Varying CO Concentrations:

10 min at 0.1 V, **Ionomer Impact**


Temp: 30°C, Flowrate: 100 sccm,
Ambient Pressure



Proposed Operating Mode Demonstrated (FY18)

200 sccm H₂

A7 Periodic Surface Cleaning: 200 sccm
Baseline H₂, 500ppb CO/H₂ and 50ppm CO/H₂



Ave. Response Time:

500ppb CO: **3.48 min**

50ppm CO: **1.5 min**

- Apply periodic cleanup voltages (1.5V for 30s) and measure current during 15 minute recovery intervals. (**Current kept in operating window**)

- Alarm trigger level can be set (e.g. 20 mA).


- Analyzer current loss tracks with CO concentration.

- Higher H₂ flow rate demonstrated using identical clean-up strategy.
- **Response time < 5 min (goal).**
- Total current loss similar for 100(not shown) and 200 sccm flow rates

UNCLASSIFIED

Proposed Operating Mode Demonstrated (FY18)

SAE 2719 Level



Ave Response Time: 6.9 min


Adjusted Trigger Level
Ave Response Time: 2.5 min

- Sensitivity to 200ppb CO demonstrated.
- Analyzer response time > 5 min. **(goal not met)**
- Adjusting trigger level allows 200ppb CO to alert in **2.5 min.**

UNCLASSIFIED

Testing in Real-World Conditions (FY19)


- Operation in the field may presents challenges not captured with laboratory testing. For example,
 - Sensitivity in the field
 - Maintaining stability
 - Analyzer cell lifetime
 - Durability issues
 - Local temp swings



Analyzer set-up for testing in the field

UNCLASSIFIED


Field Trials (FY19)




- Operating mode: 0.1V hold with periodic cleaning pulse applied, 1.5V. **(left graph)**
- Data shown without pulses **(right graph)** :
 1. Research grade (RG) H_2 sampled until reformer began.
 2. CO present during reformer start-up evident by sharp current decay.
 3. Performance recovers after returning to RG H_2
 4. Current increases as product gas becomes cleaner.

UNCLASSIFIED

Impact of Ambient Temp (FY19)



T swings affect baseline stability




Modifications provided stable baseline.

Modifications made to mitigate impact of local temp:

1. Insulation applied to exterior manifold and supply gas lines.
2. Internal sample loop installed to allow sample gas temp more time to equilibrate.



Insulation applied





Gas sample loop

UNCLASSIFIED

Field Results (FY19): SAE/ISO CO Level

Offline
Analysis

- New enclosure for HCD testing equipment
- Certified 200ppb bottles of CO/H₂ mixtures are not commercially available.
- A low pressure bottle (<25psi) of test gas was prepared using a NIST traceable standard.
- Raw data(left) plot shows measured current value (0.1V polarization) with clean-up voltage (1.5V) and without on the right.



- HCD successfully detected 200ppb CO outside of laboratory conditions.
- A large current loss is observed when 200ppb CO is injected into the H₂F hydrogen stream.


UNCLASSIFIED

New HCD and Components for Low-Cost System

- Present retail cost, not including labor, recently estimated to be **\$3215/system**.
- Compare to previous system field-tested at Burbank H2F which cost **\$22,500** not including the cost of the required refrigerated instrument cabinet.



- ✓ Machined Ti HCD plates: \$400/set
- ✓ Membrane/GDLs/GDE WE/CE: ~ \$50ea
- ✓ Peltier thermal module: \$175
- ✓ Peltier controller: \$750
- ✓ Machined Al adapter plate: ~ \$240ea
- ✓ VI Controls HCD controller: \$1500ea
- ✓ Misc: ~\$100/unit

- Relay and MOSFET added for external control of H2Frontier E-stop system to shut down H₂ delivery to storage if CO rises above 200 ppb from methane reformer system.
- Arduino based system



Gen 2: Peltier thermal module controls temperature for flexible deployment

Gen 1 Field test at Burbank: HCD and Gamry unit were placed inside refrigerated enclosure already onsite.



UNCLASSIFIED

Validation and Verification Testing HCD

- HCD test results provided by **Skyre** reproduce the performance characteristics and testing results obtained at LANL and at the H2Frontier hydrogen fueling station.
- Low cost (Gen2) HCD performance comparable to Gen1

Results from Skyre (CRADA final report)




Figure 6. Evaluation of 2nd Gen HCD functionality – CA sensing-cleaning cycles for the verification of contamination-recovery in 2.0, 1.0, 0.4 & 0.2 ppm CO in H₂

2nd Gen HCD performance in 0.2, 0.4, 1.0, and 2.0 ppm CO




Figure 5. First-Generation HCD's contamination-recovery in 0.2 PPM CO in Zero H₂

1st Gen HCD performance in 200ppb CO

Contaminant Concentration vs. HCD test parameters	Zero-Grade H ₂	2 ppm CO in H ₂	1 ppm CO in H ₂	0.4 ppm CO in H ₂	0.2 ppm CO in H ₂
Baseline Current (mA)	30	30	25	28	28
Current Upon Contamination (mA)	N/A	12	12	20	22
% of Contamination	0%	60%	52%	29%	21%
Recovery of Baseline	Yes	Yes	Yes	Yes	Yes
Cell Resistance (Ohm)	1.2-1.3	1.5-1.7	1.3-1.5	1.5-1.7	1.4-1.7

Table 1. 1st Gen HCD evaluation parameters for different CO-concentration in Zero-grade H₂ gas

1st Gen HCD performance in 0.2, 0.4, 1.0, and 2.0 ppm CO

UNCLASSIFIED

Developing an Inline HCD


Approach

Replace Nafion[®] with a proton-conducting thermoplastic membrane that will not require water to function.

Polybenzimidazole (PBI) based HCD work




PBI membranes prepared by LANL researchers with 5, 10, and 15% H₃PO₄.



Same HCD hardware used but humidification scheme not used.

Excess H₃PO₄ applied to GDE/GDL before assembly.





Same sputtered, low-Pt loaded GDL used / PtRu CE. With or without ionomer.

UNCLASSIFIED


HCD: Initial PBI Results

- Use identical operating mode
- Current response to higher concentration CO similar to Nafion[®] HCD.
- Impedance spectra: an increase in charge transfer resistance is indicative of catalyst poisoning (i.e. CO adsorption)
- No response to CO at the SAE level
- Cell conditioning different from Nafion[®] based HCD.



UNCLASSIFIED

PBI-based HCD Flowrate Impact:





- *No water reservoir*
- *Flow independent baseline current*
- *Initial performance lower*

PBI-based HCD operated in completely water-free, dry H₂ stream. The current response remained constant even after a 5X increase in flowrate.

UNCLASSIFIED

PBI HCD: Sensitivity Tuning



- Test conditions: 30°C, ambient pressure, 500sccm flowrate, identical reference electrodes
- Previous Slide: **Pumping Current: ~0.0045 A** (Ultra-low Pt loadings with 10M H₂PO₄)
- Modified [H₂PO₄] and Pt loading
- **Left graph:** Varying local [H₂PO₄] significantly changes membrane conductivity (HFR).
- **Right graph:** Pumping Current is influenced by both [H₂PO₄] and Pt loading

Successfully varied the HCD pumping current!!!

UNCLASSIFIED

Summary

- HCD improved in several iterations
 - Component modification to stabilize membrane hydration
 - Ionomer content varied for baseline stability and improved conditioning
 - Clean up strategy implemented to reset analyzer
- Sensitivity to 200ppb CO in dry H₂ has been demonstrated
- Patent filed for technology
- Field trials location identified, system installed and tested
- Less expensive Gen 2 electronics development after proven field trials testing
- Inline HCD(PBI-based) shows promise but has challenges with sensitivity

UNCLASSIFIED

Acknowledgements

- Our funding source:
 - Laura Hill (Technology Manager, DOE HFTO)
- Collaborators:
 - H2Frontier (Burbank, CA)
 - SKYRE (Formerly Sustainable Innovations)
 - NREL, Bill Buttner
 - VI Control Systems of Los Alamos
- And the Audience!!!

Thank you

UNCLASSIFIED