

LA-UR-21-32059

Approved for public release; distribution is unlimited.

Title: Automated Tuning IO Parameters for Line X-C

Author(s): Watkins, Heath Andrew

Montgomery, Jeffrey M.

Intended for: Report

Issued: 2021-12-09





Automated Tuning IO Parameters for Line X-C

Jeff Montgomery, MSTS Heath Watkins, LANL

12/7/2021

Goals

To determine the parameters that are needed for tuning the beam, and devise a structure sufficient for accessing, reading, and writing those parameters.

The main problem here is that the beam physicist (BP) is the best, and only, agent who can determine which parameters they want to use to tune.

BP determines tuning parameters




What is a "tune"?


(from a software standpoint)

Since the "best tuning parameters" are specifically associated with the parameters the beam physicist decided to change AND the parameters they chose to keep fixed, a given "tune" is actually a set of all relevant machine parameters, a list of which parameters are being varied, and the initial and final values for both sets of parameters.

Also includes metadata i.e. date/time/beam characteristics/etc...









Overall map of the end of line X and lines B and C This picture is slightly outdated. More accurate version available, but unnecessary at this step.





Division of "responsibility" along lines X and C. "Beam Tuning" operators generally refer to everything before LCTV04, but this is not necessarily a hard rule.






Division of "responsibility" along lines X and C. "Beam Tuning" operators generally refer to everything before LCTV04, but this is not necessarily a hard rule.



Phosphor+TV positions along Line X-C




Phosphor + TV positions along line X and C Used for piecewise tuning/focusing elements before each TV



What things are

TV	Television + Phosphor	QM	Quadrupole Magnet
	(insertable/removable)	PM	Position Monitor (BPM, BPPM)
CM	Current Monitor	BS	Beam Stop
DF	Diffuser	SV	Solenoid Valve
AP	Loss Monitor	TG	Vacuum Thermocouple
IG	Ion Gauge (vacuum)	WS	Wire scanner
IP	Ion Pump	ST	Beam stripper
KI	Kicker	XM	Transmission monitor
BM	Bending Magnet		
SM	Steering Magnet	XL	Transmission limiter





Approximately 80 devices labeled in this picture, more existing upstream to LXBM000



LANSCE-RM Device Database System


http://db.lcs.lanl.gov/pvrprt/

Allows for obtaining PV names and descriptions from device names.

For this example, we are selecting "LCTV1" and a series of relevant channel column info.

This is important for constructing the "TV" object datatype that we will use to access and live analyze phosphor data.

Cameras are *mostly* standardized in terms of PV names, but other devices can be less so. An effort will need to be made to go through every device to match PV names to the intended device control parameter.



ips: (1) By clicking the Get Report button without selecting any item in the three dropdown lists and without inputting anything in text slots, you can get a default report which includes the columns of channel name, channel type, IOC name, DESC, DTYP, INP, and OUT. (2) wildcards "*" or "?" are allowed in the text fields to match anything. If the patten itself has "*" or "?", use "*" or "*" instead. (3) For the channel text field, you are allowed to input more than one patterns separated by lines, that is, one line has one pattern.



LANSCE-RM Device Database System


http://db.lcs.lanl.gov/pvrprt/

Allows for obtaining PV names and descriptions from device names.

For this example, we are selecting "LCTV1" and a series of relevant channel column info

This is important for constructing the "TV" object datatype that we will use to access and live analyze phosphor data.

Cameras are *mostly* standardized in terms of PV names, but other devices can be less so. An effort will need to be made to go through every device to match PV names to the intended device control parameter.




ips: By clicking a table header, you can sort the records with their respective columns either by ascending order or by descending order in toggle.



LANSCE-RM Device Database System

http://db.lcs.lanl.gov/pvrprt/



Similar table for LC steering magnet 2, i.e. LCSM002.

PV info is also displayed for the selected PV. Here we have the current setpoint value readback value selected.



Tips: By clicking a table header, you can sort the records with their respective columns either by ascending order or by descending order in toggle.



To do:

- Go through and tally/list the actual current existing tuning-relevant devices for all of lines X and C.
- Categorize each into a device type into an object which contains ALL necessary properties that must be stored and set into each PV for the tuning algorithm, and identify each as input or output parameters.
- Identify POSITIONS along the beam path for each device, or identify a ranking system. This will be necessary to ensure that operators cannot attempt to optimize a beam metric using a beam parameter that is downstream from that metric
 - For instance, a steering/bending/focusing magnet downstream from an intercepting TV/phosphor cannot be included in the optimization of that phosphor's image position. Same applies to current/loss monitors, position monitors, etc...
- Use the list and the object definitions to build an overall data structure for a given tune, along with packing/unpacking and read/write functions that use that data to build/access PV monitors and streaming PV setting functions for those **PVs**

