

LA-UR-22-21017

Approved for public release; distribution is unlimited.

Title: Microstructural Effects of PETN on Detonator Performance

Author(s): Ulrich, Timothy James II
Rougier, Esteban
Duque, Amanda Lynn

Intended for: HE Managers Meeting 11/09/2022

Issued: 2022-02-07



Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by Triad National Security, LLC for the National Nuclear Security Administration of U.S. Department of Energy under contract 89233218CNA000001. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

Microstructural Effects of PETN on Detonator Performance

Connecting powder characteristics to ultimate
performance to facilitate *design for qualification*

PI: TJ Ulrich (Q-6)

Co-PI's: Amanda Duque (Q-5) and Esteban Rougier (EES-17)


2/23/2021

Strategic Motivation


- ~~*Diamond Stamping*~~ Design for qualification of HE powder (primarily PETN) for detonator production would reduce production costs and facilitate certification and qualification of detonators.
- ~~*Is diamond stamping possible?*~~ What is required to facilitate *design for qualification*?
- Need to understand:
 - material characteristics important to performance
 - how to most appropriately measure/monitor these characteristics
 - evolution of these characteristics through lifetime and storage conditions

Technical Motivation


- Design, manufacturing, performance, aging, etc. are all dependent upon various material properties, from chemical (species, phase, concentrations, etc.), morphological (particle size, distribution, packing density, etc.) and mechanical (microstructure, moduli, shock propagation, etc.)
- Fisher sub-sieve surface area (FSSA) is the only characterization technique correlating to performance that is routinely in use. *Poorly understood as to why this is the only reliable metric.*
- Loose powder characterization alone is insufficient to understanding performance and aging connections.
- ***Lacking in characterization techniques for consolidated pellets.***
- Currently employed simulation techniques cannot explicitly capture microstructural physics. New FDEM capability can directly utilize microstructure, shedding light on important connections to performance.



PETN particle shapes/sizes
create complex microstructures



FSSA correlates to performance but
is NOT a microstructural characterization




Microstructure (here, porosity and force chains)
affect initiation and propagation

Proposal Concept

- Microstructure arises from a combination source material (particle morphology) and processing (e.g., pressing).
- Microstructure affects final performance characteristics
- Goals:
 - Provide new characterization methods for pellet form
 - Understand the effect of powder characteristics on the microstructure and performance of detonator pellets
 - Use new understanding to determine suitable replacement for the Fisher measurement, if possible.
 - Provide predictive modeling capability for future design, certification and qualification efforts. [*complimentary to full-scale detonator modeling effort, not duplicative*]

Integration Concept Overview



Recent Developments for Pellet Characterization

- Resonant Ultrasound Spectroscopy (Material Properties)
- Nonlinear Resonant Ultrasound Spectroscopy (Material Integrity)

Development conducted using Mock HE (900-24, IDOX, and PETCA)

Summary of Report LA-CP-21-20935: *Resonant Ultrasound Spectroscopy on Mock High Explosive Pellets*


Enabling Technology (Coming to TA-9 summer '21): Resonance Inspection Techniques & Analyses (RITA[®])

Using vibrational resonant response of a structure for:

ARS: Acoustic Resonance Spectroscopy for signature identification and “finger-printing”


RUS: Resonant Ultrasound Spectroscopy for measuring material properties (elastic constants, density)

NRUS: Nonlinear RUS for damage detection & quantification




Portable RITA[®] system (pictured).

ARS



Quick sorting of parts


RUS



Material properties
(moduli, wave speeds, density)

$$C_{ijkl}, v_{L,S}, \rho$$



NRUS




Material Integrity Quantification
and Damage Monitoring

Resonant Ultrasound Spectroscopy (RUS)

- Measuring resonance requires:
 - Source of vibration (e.g., stepped sine, noise, impulse).
 - Vibration sensor (scanning laser vibrometry strongly preferred)
- Resonance spectra depend upon:
 - material properties (elastic tensor C_{ij} , mass density ρ),
 - Geometry ($\Gamma(x,y,z)$), and
 - boundary conditions (BC).
- Obtaining properties (material, geometric, BC) requires:
 - Vibrational measurements (mode shapes and frequencies)
 - Precise geometry
 - Numerical inversion scheme






Portable RITA[®] system (pictured).




Enhanced RUS (Recent Advancements)

- Scanning Laser Vibrometry: (*measurement*)
 - Enables modal identification
 - Enables non-contact measurements
- Finite Element Modeling: (*computational*)
 - Enables complex geometries and boundary conditions
 - Enables multi-material RUS
 - Required to take advantage of modal ID from laser vibrometry
- Robust Inversion Schemes: (*algorithmic*)
 - Provides greater confidence in results
 - Allows for inversion of density and geometry




Application of RUS to Mock HE

Example: pellet pressed into an Al cup
Determine: Elastic properties and density



Mock HE Sample

LDV Measurement Point




Laser Vibrometer

Material	Density (kg/m ³)	C ₁₁ (GPa)	C ₄₄ (GPa)	Young's modulus (GPa)	Poisson's ratio	RMS Error (%)
PETCA	1176.71	6.21	1.34	3.65	0.362	0.2737
PETCA	1154.0	6.24	1.31	3.59	0.367	0.30181





















Application of RUS for Anisotropy

- HE pellets are polycrystalline aggregates consolidated through pressing.
- Single crystal properties are anisotropic.
- Random orientation of crystals in pellet *usually* result in isotropic properties.
- However, texturing can occur, e.g., due to off axis pressing, particle morphology, or other material and/or processing variations.



Anisotropy and texture in pressed pellet from RUS

- Anisotropy and texture changes the observed modal vibrations

Data	Material Type	Mode 1	Mode 2	Mode 3	Mode 6	Mode 7	Inversion RMS Error
Measured	NA						NA
Simulated	Isotropic						1.69%
Simulated	Transverse Isotropic						3.25%
Simulated	Transverse Isotropic Euler Rotation						1.57%



Resulting properties from RUS inversion

- Modal ID is an essential enhancement for determining properties in the presence of anisotropy and texture.


Elastic Symmetry	C_{11} (GPa)	C_{44} (GPa)	C_{33} (GPa)	C_{66} (GPa)	C_{13} (GPa)	α (deg.)	β (deg.)	γ (deg.)	ρ (kg/m ³)	Err (%)
Isotropic	2.35	1.03	--	--	--	--	--	--	1837	1.69
Transverse Isotropic	3.11	0.98	8.63	5.82	2.58	0.0	0.0	--	1837	3.25
Rotated Transverse Isotropic	3.23	0.96	8.15	5.81	2.98	53.68	12.56	--	1837	1.57



Nonlinear Resonant Ultrasound Spectroscopy (NRUS)


- Quantify hysteretic nonlinear elastic parameter (α) from the natural resonances (f , Δf) of an object driven at multiple strain (ϵ) amplitudes.

$$\frac{\Delta f}{f} = \alpha \epsilon$$





Resonance Inspection Techniques & Analyses (RITA) system previously developed for testing of weapons components.

Portable **RITA**® system (pictured).



Application of NRUS



- Granular materials typically exhibit nonlinear elastic behavior (i.e., amplitude dependent resonance frequency)
- Degree of nonlinear behavior (i.e., amount of frequency shift) relates to the quality/integrity of the consolidation.
- Can this be used as a performance predictor?


NRUS connection to detonator performance

- NRUS applied to aged PETN pellets

Summary of PEP, Schulze et al (2019)


NRUS Example: Thermally Aged PETN pellets

- Can we resolve differences between a pristine pellet and an aged pellet using nonlinear techniques (NRUS)?
- NRUS measurements can be made (below)




- Results (right) appear to have a lot of variability with aging time, but generally increases in α are observed

Schulze et al (2019)






Test Fire Results – Donahue and Schulze

- Rearrange pellets ordered by increasing α .
 - Define ten bins, 15 pellets each,
 - Conduct test fire for threshold determination of each bin.



Test Fire Results:

- Firing threshold does not show significant relationship to aging period – left.
- Hysteretic elastic parameter, α , shows strong correlation to performance (threshold) – center.
- Right: correlation between threshold and aging period (green) vs threshold and α (red).



Current Efforts

- Workflow optimizations: (Ph.D. student Luke Beardslee, PSU)
 - Number and location of best measurement locations
 - Automated machine learning (ML) modal ID algorithms
 - Physics informed ML for improved (and faster) inversions
- NRUS inversion for bond/interface properties (e.g., grain-grain contacts) (Post-doc Paul Geimer)
- Connect RUS and NRUS properties to other performance metrics (Ph.D. student Anna Buckthorpe, PSU)
- Application of RUS and NRUS to other detonator materials (e.g., headers, full DCA's) as well as to other systems (e.g., diffusion bonds, on-machine inspection, AM materials/components, vessel qualification, etc.)
- In situ deployment (embedded sensing, micro-reactors, flight testing)